Refrigerator
user manual



This manual is made with 100 % recycled paper.

imagine the possibilities

Thank you for purchasing this Samsung product.

SAMSUNG

Free Standing Appliance

Contents

SAFETY INFORMATION 2
SETTING UP YOUR REFRIGERATOR 18
OPERATING YOUR SAMSUNG REFRIGERATOR 26
TROUBLESHOOTING 33

Safety information

SAFETY INFORMATION

- Before operating the appliance, please read this manual thoroughly and retain it for your reference.
- Use this appliance only for its intended purpose as described in this instruction manual.
  This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
  Children shall not play with the appliance.
  Cleaning and user maintenance shall not be made by children without supervision.
- Warnings and Important Safety Instructions in this

DA68-03194K-00.indb 2 2015. 5. 29. 2:21

manual do not cover all possible conditions and situations that may occur. It is your responsibility to use common sense, caution, and care when installing, maintaining, and operating your appliance.

- Because these following operating instructions cover various models, the characteristics of your refrigerator may differ slightly from those described in this manual.
  R-600a or R-134a is used as a refrigerant.
  Check the compressor label on the rear of the appliance or the rating label inside the fridge to see which refrigerant is used for your refrigerator.
  When this product contains flammable gas (Refrigerant R-600a), contact your local authority in regard to safe disposal of this product.
- In order to avoid the creation of a flammable gas-air mixture if a leak in the refrigerating circuit occurs, the size of the room in which the appliance may be sited depends on the amount of refrigerant used.
- Never start up an appliance showing any signs of damage.
  If in doubt, consult your dealer.
  The room must be 1 m^3 in size for every 8 g of R-600a refrigerant inside the appliance.
  The amount of refrigerant in your particular appliance is shown on the identification plate inside the appliance.
- Refrigerant squirting out of the pipes could ignite or cause an eye injury.
  When refrigerant leaks from the pipe, avoid any naked flames and move anything flammable away from the product and ventilate the room immediately.

- Failing to do so may result in fire or explosion.

DA68-03194K-00.indb 3 2015. 5. 29. 2:21

Important safety symbols and precautions:

WARNING	Hazards or unsafe practices that may result in **severe personal injury or death.**
CAUTION	Hazards or unsafe practices that may result in **minor personal injury or property damage.**

	Do NOT attempt.
	Do NOT disassemble.
	Do NOT touch.
	Follow directions carefully.
	Unplug the power plug from the wall socket.
	Make sure the machine is grounded to prevent electric shock.
	Call the contact center for help.
	Note.

These warning signs are here to prevent injury to you and others.
Please follow them carefully.
After reading this section, keep it in a safe place for future reference.

CE Notice

This product has been determined to be in compliance with the Low Voltage Directive (2006/95/EC), the Electromagnetic Compatibility Directive (2004/108/EC), RoHS Directive (2011/65/EU), Commission Delegated Regulation (EU) No 1060/2010 and the Eco-Design Directive (2009/125/EC) implemented by Regulation (EC) No 643/2009 of the European Union.
(For products sold in European Countries only)

DA68-03194K-00.indb 4 2015. 5. 29. 2:21

⚠ WARNING SEVERE WARNING SIGNS FOR TRANSPORTATION AND SITE

- When transporting and installing the appliance,care should be taken to ensure that no parts of the refrigerating circuit are damaged.

- Refrigerant leaking from the pipe work could ignite or cause an eye injury.
  If a leak is detected, avoid any naked flames or potential sources of ignition and air the room in which the appliance is standing for several minutes.
- This appliance contains a small amount of isobutane refrigerant (R-600a), a natural gas with high environmental compatibility that is, however, also combustible.
  When transporting and installing the appliance, care should be taken to ensure that no parts of the refrigerating circuit are damaged.

⚠ WARNING SEVERE WARNING SIGNS FOR INSTALLATION

- Deteriorated insulation of electrical parts may cause an electric shock or fire.
- Do not place this refrigerator in direct sunlight or expose to the heat from stoves, room heaters or other appliance.
- Do not plug several appliances into the same multiple power board.
  The refrigerator should always be plugged into its own individual electrical outlet which has a voltage rating that matched the rating plate.
- This provides the best performance and also prevents overloading house wiring circuits, which could cause a fire hazard from overheated wires.
- If the wall socket is loose, do not insert the power plug.
- There is a risk of electric shock or fire.
- Do not use a cord that shows cracks or abrasion damage along its length or at either end.

DA68-03194K-00.indb 5 2015. 5. 29. 2:21

- Do not pull or excessively bend the power cord.
- Do not twist or tie the power cord.
- Do not hook the power cord over a metal object, place a heavy object on the power cord, insert the power cord between objects, or push the power cord into the space behind the appliance.

- When moving the refrigerator, be careful not to roll over or damage the power cord.
- This may result in an electric shock or fire.

- Do not use aerosols near the refrigerator.

- Aerosols used near the refrigerator may cause an explosion or fire.
- Do not bend the power cord excessively or place heavy articles on it.

- This refrigerator must be properly installed and located in accordance with the manual before it is used.

- Do not install the refrigerator in a damp place or place where it may come in contact with water.

- Deteriorated insulation of electrical parts may cause an electric shock or fire.

- Connect the power plug in proper position with the cord hanging down.

- If you connect the power plug upside down, wire can get cut off and a cause fire or an electric shock.

- Make sure that the power plug is not squashed or damaged by the back of the refrigerator.

- When moving the refrigerator, be careful not to roll over or damage the power cord.

- This constitutes a fire hazard.

- Keep the packing materials out of reach of children.

- There is a risk of death from suffocation if children put them on their head.

- This appliance should be positioned in such a way that it is accessible to the power plug.

- Failing to do so may result in an electric shock or fire due to electric leakage.

- Do not install this appliance near a heater, inflammable material.

DA68-03194K-00.indb 6 2015. 5. 29. 2:21

- Do not install this appliance in a humid, oily or dusty location, in a location exposed to direct sunlight and water (rain drops).
- Do not install this appliance in a location where gas may leak.
  - This may result in an electric shock or fire.
- If any dust or water is in the refrigerator, pull out power plug and contact your Samsung Electronics service center.
  - Otherwise there is a risk of fire.
- Do not stand on top of the appliance or place objects (such as laundry, lighted candles, lighted cigarettes, dishes, chemicals, metal objects, etc.) on the appliance.
  - This may result in an electric shock, fire, problems with the product, or injury.

- This appliance must be properly grounded.
- Do not ground the appliance to a gas pipe, plastic water pipe, or telephone line.
  - You must ground the refrigerator to prevent any power leakages or electric shocks caused by current leakage from the refrigerator.
  - This may result in an electric shock, fire, explosion, or problems with the product.
  - Never plug the power cord into a socket that is not grounded correctly and make sure that it is in accordance with local and national codes.

- If the power cord is damaged, have it replaced immediately by the manufacturer or its service agent.
- The fuse on the refrigerator must be changed by a qualified technician or service company.
  - Failing to do so may result in an electric shock or personal injury.

DA68-03194K-00.indb 7 2015. 5. 29. 2:21

⚠ CAUTION CAUTION SIGNS FOR INSTALLATION

- Keep ventilation opening in the appliance enclosure or mounting structure clear of obstruction.
- Allow the appliance to stand for 2 hours before loading foods after installation and turning on.
- The installation or any service of this appliance is recommended by a qualified technician or service company.
  - Failing to do so may result in an electric shock, fire, explosion, problems with the product, or injury.
- When installing the refrigerator, make sure both legs contact the floor for secure installation.
  Legs are located at the bottom back of freezer door. Insert a flathead screwdriver and turn it in the direction of the arrow until it is level.
- Always balance the load on each door.
- Overload on any one door may fell the refrigerator, causing physical injury.

⚠ WARNING SEVERE WARNING SIGNS FOR USING

- Do not touch the power plug with wet hands.
  - This may result in an electric shock.
- Do not store articles on the top of the appliance.
  - When you open or close the door, the articles may fall and cause a personal injury and/ or material damage.
- Do not put items filled with water on the refrigerator.
  - If spilled, there is a risk of fire or electric shock.
- Do not touch the inside walls of the freezer or products stored in the freezer with wet hands.
  - This may cause frostbite.
- Do not use or place any substances sensitive to temperature such as inflammable sprays, inflammable objects, dry ice, medicine, or chemicals near the refrigerator.
  Do not keep volatile or inflammable objects or substances (benzene, thinner, propane gas, alcohol, ether, LP gas and other

DA68-03194K-00.indb 8 2015. 5. 29. 2:21

such products etc.) in the refrigerator.
- This refrigerator is for storing food only.
- This may result in a fire or an explosion.

• Do not store pharmaceuticals products, scientific materials or temperature-sensitive products in the refrigerator.
- Products that require strict temperature controls must not be stored in the refrigerator.

• Do not place or use electrical appliance inside the refrigerator/freezer, unless they are of a type recommended by the manufacturer.

• If you smell pharmaceutical or smoke, pull out power plug immediately and contact your Samsung Electronics service center.

• If any dust or water is in Refrigerator, pull out power plug and contact your Samsung Electronics service center.
- Otherwise there is a risk of fire.

• If gas leak is detected, avoid any naked flames or potential sources of ignition and air the room in which the appliance is standing for several minutes.

• Do not use mechanical devices or any other means to accelerate the defrosting process, other than those recommended by the manufacturer.

• Do not damage the refrigerant circuit.

• Do not spray volatile material such as insecticide onto the surface of the appliance.
- As well as being harmful to humans, it may also result in an electric shock, fire or problems with the product.

• Do not use a hair dryer to dry the inside of the refrigerator. Do not place a lighted candle in the refrigerator for removing bad odours.
- This may result in an electric shock or fire.

• Fill the water tank, ice tray, water cubes only with potable water.
- Do not fill tea or sports drink, this may cause the damage of refrigerator.

DA68-03194K-00.indb 9 2015. 5. 29. 2:21

- Do not let children hang on the door.
  If not, a serious injury may occur.
- Risk of children entrapment. Do not let children enter inside the refrigerator.
- Do not leave the doors of the refrigerator open while the refrigerator is unattended and do not let children enter inside the refrigerator.
- Do not allow babies or children go inside the drawer.
- It can cause death from suffocation by entrapment or personal injury.
- Do not sit on the Freezer door.
- The door may be broken and cause a personal injury.
- To prevent children entrapment, you must reinstall the divider using provided screws after cleaning or other actions if you removed the divider from the drawer.
- Do not use mechanical devices or any other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not damage the refrigerant circuit.

- In the event of a gas leak (such as propane gas, LP gas, etc.), ventilate immediately without touching the power plug. Do not touch the appliance or power cord.
- Do not use a ventilating fan.
- A spark may result in an explosion or fire.
- Use only the LED Lamps provided by manufacturer or service agent.
- Children should be supervised to ensure that they do not play with the appliance.
- Keep fingers out of “pinch point” areas; clearances between the doors and cabinet are necessarily small.
- Do not let children hang on the door.
  If not, a serious injury may occur.
- There is a Risk of children entrapment.
  Do not let children enter inside the refrigerator.
- Bottles should be stored

DA68-03194K-00.indb 10 2015. 5. 29. 2:21

tightly together so that they do not fall out.

- This product is intended only for the storage of food in a domestic environment.
- Never put fingers or other objects into the dispenser hole, ice chute and ice maker bucket.
- It may cause a personal injury or material damage.
- Do not insert hands, feet or metal objects (such as chopsticks, etc.) into the bottom or the back of the refrigerator.
- This may result in an electric shock or injury.
- Any sharp edges may cause a personal injury.

- Do not attempt to repair, disassemble, or modify the appliance yourself.
- Do not use any fuse (such as cooper, steel wire, etc.) other than the standard fuse.
- When repairing or reinstalling the appliance is required, contact your nearest service center.
- Failing to do so may result in an electric shock, fire, problems with the product, or injury.

- If the appliance generates a strange noise, a burning or smell or smoke, unplug the power plug immediately and contact your nearest service center.
- Failing to do so may result in an electric or fire hazards.
- Pull the power plug out of the socket before changing the interior lamps of the refrigerator
- Otherwise, there is a risk of electric shock.
- If you experience difficulty when changing the light, contact service agent.
- If the products is equipped with the LED Lamp, do not disassemble the Lamp Cover and LED Lamp by yourself.
- Please contact your service agent.
- Plug the power plug into the wall socket firmly.
  Do not use a damaged power plug, damaged power cord or loose wall socket.
- This may result in an electric shock or fire.

DA68-03194K-00.indb 11 2015. 5. 29. 2:21

• Do not put a container filled with water on the appliance.
- If spilled, there is a risk of fire or electric shock.
• Never stare directly at the UV LED lamp for long periods of time.
- This may result in eye strain due to the ultraviolet rays.

⚠ CAUTION SIGNS FOR USING

• To get best performance from the product,
- Do not place foods too closely in front of the vents at the rear of the appliance as it can obstruct free air circulation in the refrigerator compartment.
- Wrap the food up properly or place it in airtight containers before putting it into the refrigerator.
- Do not put any newly introduced food for freezing near to already existing food.
• Do not place glass or bottles or carbonated beverages into the freezer.
- The container may freeze and break, and this may result in injury.
• Please observe maximum storage times and expiry dates of frozen goods.
• Do not store low temperature-sensitive pharmaceutical products, scientific materials or other low temperature-sensitive products in the refrigerator.
- Products that require strict temperature controls must not be stored in the refrigerator.
• There is no need to disconnect the refrigerator from the power supply if you will be away for less than three weeks.
But, remove all the food if you are going away for the three weeks or more.
Unplug the refrigerator and clean it, rinse and dry.
• Do not place carbonated or fizzy drinks in the freezer compartment.
Do not put bottles or glass containers in the freezer.
- When the contents freeze, the glass may break and

DA68-03194K-00.indb 12 2015. 5. 29. 2:21

cause personal injury and property damage.

- Do not modify the refrigerator. Unauthorized modifications can cause safety problems. To reverse an unauthorized modification, we will charge the full cost of parts and labor.
- Do not change or modify the functionality of the refrigerator.

- Changes or modifications may result in a personal injury and/or property damage. Any changes or modifications performed by a 3rd party on this completed appliance are neither covered under Samsung warranty service, nor is Samsung responsible for safety issues and damages that result from 3rd party modifications.

- Do not block air holes.

- If the air holes are blocked, especially with a plastic bag, the refrigerator can be over cooled. If this cooling period lasts too long, the water filter may break and cause water leakage.

- Use only the ice-maker provided with the refrigerator.
- The water supply to this refrigerator must only be installed/connected by a suitably qualified person and connected to a potable water supply only.
- If you have a long vacation or business trip and won't use water or ice dispensers, close the water valve.

- Otherwise, water leakage may occur.

- Wipe excess moisture from the inside and leave the doors open.

- Otherwise, odor and mold may develop.

- When the refrigerator got wet by water, pull out the power plug and contact your Samsung Electronics service center.
- Do not apply strong shock or excessive force onto the surface of glass.

- Broken glass may result in a personal injury and/or property damage.

- Do not sit on or hang onto the door or home bar of refrigerator.

DA68-03194K-00.indb 13 2015. 5. 29. 2:21

- This may cause the refrigerator to fall over, the door to separate or a hand being caught in the crack of the door, and this may result in property damage or injury.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

⚠ CAUTION SIGNS FOR CLEANING AND MAINTENANCE

- Do not spray cleaning products directly on the display.
- Printed letters on the display may come off.
- If any foreign substance such as water has entered the appliance, unplug the power plug and contact your nearest service center.
- Failing to do so may result in an electric shock or fire.
- Remove all foreign substances such as dust or water from the power plug terminals and contact points using a dry cloth on a regular basis.
- Unplug the power plug and clean it with a dry cloth.
- Failing to do so may result in an electric shock or fire.
- Do not clean the appliance by spraying water directly onto it.
- Do not use benzene, thinner, or Clorox, Chloride for cleaning.
- They may damage the surface of the appliance and may cause a fire.

- Before cleaning or performing maintenance, unplug the appliance from the wall socket.
- Failing to do so may result in an electric shock or fire.

DA68-03194K-00.indb 14 2015. 5. 29. 2:21

⚠ WARNING SEVERE WARNING SIGNS FOR DISPOSAL

- Leave the shelves in place so that children may not easily climb inside.
- Ensure that none of the pipes on the back of the appliance are damaged prior to disposal.
- R-600a or R-134a is used as a refrigerant.
  Check the compressor label on the rear of the appliance or the rating label inside the refrigerator to see which refrigerant is used for your refrigerator.
  When this product contains flammable gas (Refrigerant R-600a), contact your local authority in regard to safe disposal of this product.
  Cyclopentane is used as an insulation blowing gas.
  The gases in insulation material require special disposal procedure.
  Please contact your local authorities in regard to the environmentally safe disposal of this product.
  Ensure that none of the pipes on the back of the appliances are damaged prior to disposal.
  The pipes shall be broken in the open space.
- If trapped inside, the child may become injury and suffocate to death.
- Please dispose of the packaging material for this product in an environmentally friendly manner.
- Keep all packaging materials well out of the reach of children, as packaging materials can be dangerous to children.
- If a child places a bag over its head, it may result in suffocation.

DA68-03194K-00.indb 15 2015. 5. 29. 2:21

ADDITIONAL TIPS FOR PROPER USAGE

- In the event of a power failure, call the local office of your Electricity Company and ask how long it is going to last.
- Most power failures that are corrected within an hour or two will not affect your refrigerator temperatures. However, you should minimize the number of door openings while the power is off.
- But should the power failure last more than 24 hours, remove all frozen food.
- If keys are provided with the refrigerator, the keys should be kept out of the reach of children and not be in the vicinity of the appliance.
- The appliance might not operate consistently (possibility of defrosting of contents or temperature becoming too warm in the frozen food compartment) when sited for an extended period of time below the cold end of the range of temperature for which the refrigerating appliance is designed.
- In case of particular foods, keeping it under refrigeration can have a bad effect on preservation due to its properties.
- Your appliance is frost free, which means there is no need to manually defrost your appliance, as this will be carried out automatically.
- Temperature rise during defrosting can comply with ISO requirements.
  But if you want to prevent an undue rise in the temperature of the frozen food while defrosting the appliance, please wrap the frozen food up in several layers of newspaper.
- Any increase in temperature of frozen food during defrosting can shorten its storage life.
- Do not re-freeze frozen foods that have thawed completely.
- Contains fluorinated greenhouse gases covered by the Kyoto Protocol.
  Foam blown with fluorinated greenhouse gases.
  Foam blown additive: Perfluorohexane

DA68-03194K-00.indb 16 2015. 5. 29. 2:21

Global Warming Potential (GWP) = 9300

Saving Energy Tips

- Install the appliance in a cool, dry room with adequate ventilation.
  Ensure that it is not exposed to direct sunlight and never put it near a direct source of heat (radiator, for example).
- Not to block any vents and grilles is recommended for energy efficiency.
- Allow warm food to cool down before placing it in the appliance.
- Put frozen food in the refrigerator to thaw.
  You can then use the low temperatures of the frozen products to cool food in the refrigerator.
- Do not keep the door of the appliance open for too long when putting food in or taking food out.
  The shorter time for which the door is open, the less ice will form in the freezer.
- Allow clearance to the right, left, back and top when installing.
  This will help reduce power consumption and keep your energy bills lower.
- For the most efficient use of energy, please keep the all inner fittings such as baskets, drawers, shelves on the position supplied by manufacturer.

This appliance is intended to be used in household and similar applications such as

- staff kitchen areas in shops, offices and other working environments;
- farm houses and by clients in hotels, motels and other residential type environments;
- bed and breakfast type environments;
- catering and similar non-retail applications.

DA68-03194K-00.indb 17 2015. 5. 29. 2:21

Setting up your refrigerator

GETTING READY TO INSTALL THE REFRIGERATOR

Congratulations on your purchase of the Samsung refrigerator.
We hope you enjoy the state-of-art features and efficiencies that this new appliance offers.

Selecting the best location for the Refrigerator

Choose :

- A location with easy access to the water supply.
- A location without direct exposure to sunlight.
- A location with level (or nearly level) flooring.
- A location with enough space for the refrigerator doors to open easily.
- A location that allows sufficient space to the right, left, back, and top for air circulation.
  If the refrigerator does not have enough space, it can cause the bad influence to refrigeration efficiency and power consumption.
- A location that allows you to move the refrigerator easily if it needs maintenance or service.
- Do not install the refrigerator in locations where the temperature is over 43 °C or below 5 °C.



Depth "A"	733 mm
Width "B"	908 mm
Height "C"	1797 mm
Overall Height "D"	1825 mm





- Each measurement based on the design dimension, so it may differ depending on the measuring method.

DA68-03194K-00.indb 18 2015. 5. 29. 2:21

When moving your refrigerator

To prevent floor damage, be sure the front leveling legs are in the up position (above the floor).
Refer to “HOW TO LEVEL THE REFRIGERATOR” in the manual on page 23.

Flooring

For proper installation, you must place this refrigerator on a level, hard surface that is the same height as the rest of the floor.
This surface should be strong enough to support a fully loaded refrigerator.
To protect the finish of the flooring, cut a large section of the cardboard carton and place it under the refrigerator where you are working.
When moving the refrigerator, you need to pull and push it straight forwards or back.
Do not wiggle it from side to side.



REMOVING THE REFRIGERATOR DOORS

If the refrigerator is too large to pass through your doorway easily, you can remove the refrigerator doors.

Tools you will need (Not provided)

Philips screwdriver (+)	Flat-blade screwdriver (-)	Socket wrench (10 mm)
Pliers	Allen wrench (4 mm)	Allen wrench (5 mm)

CAUTION

- Disconnect power to the refrigerator before removing the doors or drawers.

- Be careful not to drop, damage or scratch the doors/drawers while removing them.
- Use care when you remove the doors/drawers. The doors are heavy and you could injure yourself.
- Re-attach the doors/drawers properly to avoid:
- Moisture from air leakage.
- Uneven door alignment.
- Wasting energy due to improper door seal.

DA68-03194K-00.indb 19 2015. 5. 29. 2:21

DISASSEMBLE THE FRIDGE DOORS

1. With the door closed, remove the 3 screws holding the Top Cover (A) with a Phillips (+) Screwdriver, and then remove the Top Cover with the entire wire-harnesses attached.



2. Disconnect the two wire-harnesses on the left door and one on the right door.
(It may differ by models.)



3. Pull up the Fixer Lever (B), and then pull it forward.



4. Remove the Hinge (C).



5. Lift up the Fridge Door and take it off.

CAUTION
- While disassembling and reassembling the door, make sure that the electric wires are not peeled off.
- Do not let the door fall down.

DISASSEMBLE THE FREEZER DOORS

CAUTION
- Be sure to remove the Fridge Door before removing the Freezer Door.
- Be careful with the wires attached to the bottom of the Freezer Door while disassembling.

1. With the door open, remove the screw holding the cover (A) of the Adjustable Leg at the bottom of the door with a Phillips (+) Screwdriver, and then disassemble the Connector (B).



2. Lift up and remove the Mid Hinge Cap (C) on the Door Hinge above the Freezer Door.



DA68-03194K-00.indb 20 2015. 5. 29. 2:21

3. While pushing the door in the direction of the arrow, lift up the Mid Hinge Shaft (D).



4. Being careful that the door does not touch the Mid Hinge (E), tilt the Door forward a little, and then lift it up to remove.



ASSEMBLING THE REFRIGERATOR DOORS

CAUTION
- Be sure to re-attach the Freezer Door before re-attaching the Fridge Door.
- Before re-attaching, make sure that all the wire connectors at the bottom of the Freezer Door are connected.

How to Re-Attach the Freezer Door

1. Insert the door into the lower hinge (A) in the direction of (1) and then push the door in the direction of (2).
   Take care not to scratch the door with the Mid-Hinge (B).



CAUTION
- Be careful not to damage the wires on the bottom of the door.
  Avoid stepping on them, etc.

2. Insert the Hinge Shaft (C) into the Mid Hinge Hole (D) and put on the Hinge Cap (E).

- When assembling the Hinge Shaft and the Hinge Cap, be sure to assemble them in the correct direction.



3. With the door open, join the connectors on the bottom of the door.



- Be careful not to step on or damage the connectors.

4. Attach the Adjustable Leg Cover using a Phillips (+) Screwdriver.



DA68-03194K-00.indb 21 2015. 5. 29. 2:21

How to Re-Attach the Fridge Door

1. Attach the detached Fridge Door to the Mid Hinge.

2. Slide the Fridge Hinge (A) into the fixing slot, and then press it down so that it is aligned with the hole in the door.



3. Inserting the Fixer Lever (B) in the direction of the arrow, and then flip it down to assemble.



4. Assemble the Wire Connector.



5. Attach the front of the Top Cover, and then press down on its back until it lies flat. Re-attach the screws.



CAUTION

- Assemble the Door in the reverse order of the disassembling. It is the same for both of the Fridge and the Freezer Doors.
- When the Wire Connectors are being cross-assembled, the display may not work normal.

DA68-03194K-00.indb 22 2015. 5. 29. 2:21

LEVELING THE REFRIGERATOR AND ADJUSTING HEIGHT AND GAP OF THE DOORS

How to level the refrigerator

To avoid a hazard due to instability of the refrigerator, please place the refrigerator on a horizontal support and levelled in accordance with the following instruction for installation.
Failing to do so may result in the refrigerator tipping and a personal injury.
If the front of the appliance is slightly higher than the rear, the door can be opened and closed more easily.
Setting up the refrigerator on an uneven surface will cause the refrigerator to be uneven.

- When install the refrigerator, the legs should touch the floor surely.
  The legs should be located on the back of under the each door.
  Insert it with flathead screwdriver and tighten up to arrow direction.

If the Refrigerator is put on a floor that is not level, it can cause a height difference between the doors.

- Insert a Flat-Head (-) Screwdriver into the slot in the Leveling Leg Control Lever and adjust the level by turning the Control Lever clockwise or counter-clockwise.
  When you rotate the Lever clockwise, you raise the refrigerator.
  When you rotate the Lever counter-clockwise, you lower the refrigerator.



- If the Refrigerator is not level back and front, put a solid panel (such as a plastic panel, a plastic ruler, etc.) on the floor where the rear legs will rest, and then fix it in place with plastic tape.
  When you push in the Refrigerator, make sure the rear legs rest on the panel.
- If you have a wooden floor or similar soft floor, take care not to damage the floor when pushing the Refrigerator into place.

DA68-03194K-00.indb 23 2015. 5. 29. 2:21

HOW TO ADJUST THE DOOR HEIGHT

If any one of the doors is lower than the other:



- Check if the Refrigerator is level before adjusting the door.

- Adjust the door height difference by inserting a Snap Ring (1) as shown between the door and the hinge.
  You can use the rings on the right side door of the fresh food compartment and both sides of the freezer compartment.



- After checking the height difference, select one Snap Ring with a suitable thickness. Insert one Snap Ring only, Inserting two or more Snap Rings may cause the Snap Rings to slip out or make a rubbing noise.
- Lift up the lower door and insert the Snap Ring into the space between the Door and the Hinge.

CAUTION
- To avoid injury, insert or remove Snap Rings carefully.
- Keep the Snap Rings out of the reach of children and make sure that children do not play with them or put them into their mouths.

- 1 mm, 1.5 mm, 2 mm, and 2.5 mm Snap Rings come with the Refrigerator.
- If the Refrigerator is level before you load it with food, the Refrigerator may become unbalanced due to the weight of the food.
  If this occurs, adjust the level again using the same procedure.
- If you raise the door too far, it can rub against the Top Cover.

Snap Rings included with the refrigerator:

HOW TO ADJUST THE DOOR GAP

If the gap between the left and right fridge compartment doors is not even.

- You can adjust the gap by turning the bolt at the top right of the cold storage compartment door.
- Do not turn the bolt too far. You can break it.



1. With the doors closed, remove the 3 screws holding the top cover using a Phillips screwdriver, and then lift it off together with the connected cables.



2. Turn the bolt with a 4 mm hexagonal L-wrench to adjust the gap.



3. Turn the bolt clockwise to ( ) widen the gap. Turn the bolt counter clockwise ( ) to narrow the gap.

DA68-03194K-00.indb 24 2015. 5. 29. 2:21

PRODUCT FEATURES

- **TRIPLE COOLING**
- Freezer / Fresh food compartment / convertible compartment are able to maintain optimum temperature / humidity using by each condenser.
  And also smell will not mix.

- **FLEX ZONE**
- It is able to various storage using by Freezer / Cooling / cool selection / thin ice options.

- **Chill**
- Fixed temperature technology will keep freshness.

DA68-03194K-00.indb 25 2015. 5. 29. 2:21

Operating your Samsung refrigerator

USING THE CONTROL PANEL

NORMAL MODEL



(1) Fridge

Touch the Fridge button to set the fridge to desired temperature from the range between 1 °C and 7 °C.
Default set temperature is set on 3 °C and each time you touch the Fridge button, temperature will change in following order and temperature indicator will display the desired temperature.



(2) CoolSelect+ (Cool Select Room)

Cool Select Room is located on the bottom right of refrigerator.
The CoolSelect button turn the Cool Select Room to one of 4-setting; Freezer, Soft Freezing, Chill and Cool.
To change the Cool Select Room settings, touch and hold the button for at least 3 seconds, and then release the button when a desired mode is selected.
After 3 seconds from touching the button, the mode is changed at 1 second intervals.

Freezer

Select Freezer to set the same temperature as the freezer.
- Use this setting to keep frozen food.

Soft Freezing

Select Soft Freezing to set the temperature to -5 °C.
- Use this setting to keep meat and fish fresh longer than fridge.

Chill

Select Chill to set the temperature to -1 °C.
- Use this setting to keep deli like steak, fish, bacon and cheese.

Cool

Select Cool to set the temperature to 2 °C.
- Use this setting to keep drink (juice, soft drinks and beer), vegetable, fruit, etc.

DA68-03194K-00.indb 26 2015. 5. 29. 2:21

CAUTION

- When shifting its function after using the [Freezer] function, meat blood or water may come out of meat or water containing food.

- If meat or fish is stored at the [Fridge] setting, it may get deteriorated.
  When food is not stored according to the settings of the Cool Select Room, the food may get frozen or deteriorated.

- When the button does not work, check if it is set to the Lock.
  When it is locked, touch the Lock/Unlock button for 3 seconds or more until the Unlock Icon ( ) lights on.
  And then, change the setting by touching the Cool Select Room for 3 seconds or more.
- When the setting is complete, check the display one more time to see if the setting is correct.

(3) Freezer

Touch the Freezer button to set the freezer to desired temperature from the range between -15 °C and -23 °C.
Default set temperature is set on -19 °C and each time you touch the Freezer button, temperature will change in following order and temperature indicator will display the desired temperature.

-18 °C – -19 °C – -20 °C – -21 °C – -22 °C – -23 °C
-17 °C – -16 °C – -15 °C – Power Freeze

- The Freezer or Fridge temp indicator will blink when the temperature in the fridge or freezer compartment goes up dramatically.
  (Freezer or Fridge temperature indicator will stop blinking when temperature in the Freezer or Fridge becomes normal.
  If temperature indicator does not stop blinking after several hours, please contact your service center.

Power Freezer

The Power Freeze function substantially speeds up the freezer compressor, causing the freezer to cool down rapidly to a temperature you choose.
Power Freeze is useful if you need to quick freeze an item, to make a large quantity of ice, or to cool the freezer rapidly if it has warmed dramatically (for example, if the door was left open).
To turn the Power Freeze function off manually, touch the Freezer button, and then re-set the Freezer temperature.
Power Freeze turns off automatically after 50 hours to decrease energy consumption.
When the Power Freeze function stops automatically, it automatically sets the Freezer temperature to -19 °C.
Re-set the temperature if necessary.
When you use this function, the energy consumption of the refrigerator will increase.
If you need to freeze large amounts of food, activate the Power Freeze function at least 20 hours before.

(4) Lock Unlock

Touching this button for 3 seconds locks the all buttons so the buttons can not be used.
Also, touch this button again for 3 seconds unlocks the all buttons.

DA68-03194K-00.indb 27 2015. 5. 29. 2:21

Canceling Exhibition Mode

CAUTION

- In case of Exhibition Mode, It seems working but doesn't make cool air. To cancel this mode, touching and holding both the Lock and Fridge keys at the same time for approximately 6 seconds when the refrigerator is working normally, will make the entire display panel blink every 0.5 seconds for approximately 4 seconds. During the 4 seconds when the entire display panel blinks, if you release the Lock and Fridge keys and touch the Freezer key until "Ding-dong" sounds. Or you can cancel the exhibition mode by turning the power off.

CONTROLLING THE TEMPERATURE

Recommended freezer and fridge compartment temperatures

The recommended temperatures for the Freezer and Fridge Compartments are -19 °C and 3 °C respectively.
If the temperature of the Freezer and Fridge Compartments are too high or low, adjust the temperature manually.

CONTROLLING THE FREEZER TEMPERATURE

Recommend Temp (Freezer) : -19 °C

Freezer

Touch the Freezer button to set the freezer to desired temperature from the range between -15 °C and -23 °C.
Default set temperature is set on -19 °C and each time you touch the Freezer button, temperature will change in following order and temperature indicator will display the desired temperature.

DA68-03194K-00.indb 28 2015. 5. 29. 2:21

-20 °C – -21 °C – -22 °C – -23 °C – Power Freezer

-19 °C – -18 °C – -17 °C – -16 °C – -15 °C

- The Freezer or Fridge temp indicator will blink when the temperature in the fridge or freezer compartment goes up dramatically.
  Freezer or Fridge temperature indicator will stop blinking when temperature in the Freezer or Fridge becomes normal.
  If temperature indicator does not stop blinking after several hours, please contact your service center.

CONTROLLING THE FRIDGE TEMPERATURE

Recommend Temp (Fridge) : 3 °C

Touch the Fridge button to set the fridge to desired temperature from the range between 1 °C and 7 °C.
Default set temperature is set on 3 °C and each time you touch the Fridge button, temperature will change in following order and temperature indicator will display the desired temperature.

3 °C – 2 °C – 1 °C – 7 °C

4 °C – 5 °C – 6 °C

- The temperature of the Freezer, Fridge or Cool Select Room may rise when you open the doors too frequently, or if a large amount of warm or hot food is placed inside.
- This may cause the digital display to blink. Once the Freezer and Fridge temperature return to their normal set temperatures, the blinking will stop.
- If the blinking continues, you may need to “reset” the Refrigerator.
  Try unplugging the appliance, wait for around 10 minutes, and then plug the power cord back in.
- If there is a communication error between the Display and Main Controller, Display may blink “E-PC” light may blink.
  If the blinking continues for a long period of time, please contact a Samsung Electronics Service Center.

DA68-03194K-00.indb 29 2015. 5. 29. 2:21

PARTS AND FEATURES

Use this page to become more familiar with the parts and features of the Refrigerator.



The door guards in the freezer of this model are the two star sections except the top guard, so the temperature in two star sections are slightly higher than other freezer compartment.
(**1**) is two star section.

When closing the door, make sure the Vertical Hinged Section is in the correct position to avoid scratching the other door. If the Vertical Hinged Section is reversed, put it back into the correct position, and then close the door.
Moisture may appear at times on the Vertical Hinged Section.
The door handle may become loose over time.
If this happens, tighten the bolts found on the inside of the door.
If you close one door with too much force, the other door may open.

If the interior or exterior LED lamp has gone out, please contact Samsung service.

DA68-03194K-00.indb 30 2015. 5. 29. 2:21

ICE STORAGE BOX

It is to store ice cubes.
When there is no ice consumption, take the container out of the refrigerator to get more storage room.

How to Use the Ice Storage Box

1. Support Ice Tray
- Support Ice Tray it prevents any foreign substances from entering into ice.

2. Ice Tray
- It is used to make ice cubes.

3. Ice Bin
- It is used to store ice cubes being made.

- Store the ice cubes being made by turning the Ice Tray knob clockwise ( ).
- All the ice cubes may not get separated from the tray at once.
  If so, twist the Ice Tray multiple times.
- Frozen green tea or milk may be difficult to separate from the Ice Tray.
- Lift up the ice bin and pull it out to remove it.





Knob

CAUTION
- Do not pour water into the transparent Ice Bin for the storage of the ice cubes. The Ice Bin may get cracked.

- There is a water drain hole in the bottom of the transparent Ice Bin which is designed to prevent water from being held inside.
- When storing the ice cubes at the above-zero temperature, ice may get melt down flowing out of the Ice Bin.
- Ice may get melt down flowing out of the Ice Bin due to power outage for a while.
  Also, when the melt water gets frozen again, it may break the Ice Bin.
  (Use the Ice Bin after removing melt water.)

REMOVING THE REFRIGERATOR ACCESSORIES

1. Door Bins or Guards Compartment
- To remove - Simply lift the bin up and pull straight out.
- To relocate - Slide it in above the desired location and push down until it stops.

CAUTION
- Injuries can occur if the door bins are not firmly attached to the doors.
  Do not allow children to play with longer.
  Sharp corners of the bins may cause injury.

- Do not adjust a bin full of food.
  Remove the food first.



- Dust removal method - Remove the guard and wash in water.

- Wash in water if it is stained with oil after use.



DA68-03194K-00.indb 31 2015. 5. 29. 2:21

2. Tempered Glass shelves

- To remove - Tilt up the front of the shelf in the direction shown (1) and lift it up vertically (2). Pull the shelf out.
- To relocate - Tilt the front of the shelf up and guide the shelf hooks into the slots at a desired height.
  Then, lower the front of the shelf so that the hooks can drop into the slots.

CAUTION
- The Tempered Glass shelves are heavy. Use special care when removing them.



3. Vegetable & Fruit Drawers (EZ Fresh Zone)

- Holding the drawer with one hand, lift it up a little bit while pulling it forward, and then pull it out of the refrigerator.

- Remove the door bins before removing the drawer to prevent damage to the door bins.



CLEANING THE REFRIGERATOR

WARNING
- Do not use benzene, thinner, Clorox, or car detergent to clean the refrigerator. They can damage the surface of the appliance and may cause a fire.
- Do not spray the refrigerator with water while it is plugged in, This can cause an electric shock.

- To clean the refrigerator, follow these steps:

1. Unplug the power code of the refrigerator.
2. Slightly dampen a soft lint-free cloth or paper towel with water.

Do not use any kind of detergent to clean the refrigerator because that can discolor or damage the refrigerator.

3. Wipe the inside and outside of refrigerator until it is clean and dry.
4. Plug the power code of the refrigerator back in.

CHANGING THE INTERIOR LIGHTS

Freezer / Fridge LED Lamp

- If the LED Lamp Cover is stained with foreign substances, the LED lamp may not look bright. Wipe the surface cover with clean dry cloth to return the light to full brighteness.

CAUTION
- Do not disassemble or replace the LED type lighting yourself.
  To replace the LED lights, contact a Samsung service center or your authorized Samsung dealer.

If you attempt to replace the LED lamps yourself, you risk subjecting yourself to an electric shock or serious personal injury.

DA68-03194K-00.indb 32 2015. 5. 29. 2:21

Troubleshooting

PROBLEM	SOLUTION
The refrigerator does not work at all or it does not chill sufficiently.	• Check if the power plug is properly connected. • Check if the set temperature on the digital display is warmer than the freezer or fridge inner temperature. If it is, set the freezer or fridge to a colder temperature. • Is the refrigerator in direct sunlight or located near a heat source? If so, it may not be able to cool sufficiently. Install it in a location that is out of direct sunlight and not near a heat source. • Is the back of the refrigerator too close to the wall, preventing proper ventilation? If so, it may not be able to cool sufficiently. Keep it an appropriate distance from the wall. • Is there too much food inside so that the food is blocking the outlet vent? To keep the refrigerator at a suitable temperature, do not fill the refrigerator with too much food.
The food in the fridge is frozen.	• Check if the set temperature on the digital display is too low. If so, raise the set temperature inside the refrigerator. • Is the temperature in the room too low? Set the refrigerator warmer. • Did you store food with a high moisture content in the coldest part of the refrigerator or near the cooling outlet vent? Try moving those items to the other shelves in the fridge instead of keeping them in the colder areas or bins.
You hear unusual noise or sounds.	• Check if the refrigerator is level and stable. • Is the back of the refrigerator too close to the wall, preventing proper ventilation? • Was anything dropped behind or under the refrigerator? • If you hear a “ticking” sound from inside the refrigerator, this is normal. It occurs because various parts contract or expand in response to temperature changes in the refrigerator interior. • If it sounds as if something is hitting something else inside the refrigerator, this is normal. The sound is caused by the compressor operating at high capacity.
The cabinet-door sealing area of the appliance is hot and condensation is occurring.	• Some heat is normal as anti-condensators are installed in the vertical hinged section of the refrigerator to prevent condensation. • Is the refrigerator door ajar? Condensation can occur when you leave the door open for a long time.
You can hear water bubbling in the refrigerator.	• This is normal. The bubbling comes from refrigerant circulating through the refrigerator.

DA68-03194K-00.indb 33 2015. 5. 29. 2:21

PROBLEM	SOLUTION
There is a bad smell in the refrigerator.	• Check for spoiled food. • Foods with strong odors (for example, fish) should be tightly covered. • Clean out your freezer periodically and throw away any spoiled or suspicious food.
Frost forms on the walls of the freezer.	• Is the air vent blocked? Remove any obstructions so air can circulate freely. • Allow sufficient space between the stored food for efficient air circulation. • Is the freezer drawer closed properly?
The auto close system does not work with the freezer door.	• Is there an imbalance between the right and left parts of the door? • Open and close the door smoothly 1~2 times. After you do this, the auto close system usually works properly again. • Try opening the door smoothly to avoid unbalancing the right part and the left part of the door.

DA68-03194K-00.indb 34 2015. 5. 29. 2:21

Memo

Ambient Room Temperature Limits

This refrigerator is designed to operate in ambient temperatures specified by its temperature class marked on the rating plate.

Class	Symbol	Ambient Temperature range (°C)	
		IEC 62552 (ISO 15502)	ISO 8561
Extended Temperate	SN	+10 to +32	+10 to +32
Temperate	N	+16 to +32	+16 to +32
Subtropical	ST	+16 to +38	+18 to +38
Tropical	T	+16 to +43	+18 to +43

Internal temperatures may be affected by such factors as the location of the fridge/freezer, ambient temperature and the frequency with which you open the door.
Adjust the temperature as required to compensate for these factors.

English

Correct Disposal of This Product
(Waste Electrical & Electronic Equipment)

(Applicable in countries with separate collection systems)

This marking on the product, accessories or literature indicates that the product and its electronic accessories (e.g. charger, headset, USB cable) should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources.
Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling.
Business users should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.

Contact SAMSUNG WORLD WIDE
If you have any questions or comments relating to Samsung products,
please contact the SAMSUNG customer care center.

Samsung India Electronics Pvt. Ltd. 2nd, 3rd & 4th Floor, Tower-C, Vipul Tech Square,
Sector 43, Golf Course Road, Gurgaon, Haryana, India-122002
1800 3000 8282 - Toll Free
1800 266 8282 - Toll Free
www.samsung.com/in/support

रेफ़्रिजरेटर

उपयोगकर्ता मार्गदर्शिका

Planet First 100 % Recycled Paper

यह मार्गदर्शिका 100 % पुनर्चक्रित काग़ज़ से बनी है।

संभावनाओं की कल्पना करें

यह Samsung उत्पाद खरीदने के लिए धन्यवाद।

SAMSUNG

फ़्री स्टैंडिंग उपकरण

DA68-03194K-00.indb 1 2015. 5. 29. 2:21

सामग्रियाँ

सुरक्षा जानकारी **2**

अपने रेफ्रिजरेटर को सेट करना **18**

अपने SAMSUNG रेफ्रिजरेटर को संचालित करना **26**

समस्या-निवारण **33**

सुरक्षा जानकारी

सुरक्षा जानकारी

- उपकरण के संचालन से पूर्व, कृपया इस मार्गदर्शिका को पूरी तरह पढ़ें और इसे अपने संदर्भ के लिए रखें।
- इस उपकरण को केवल इसके अभीष्ट उद्देश्य मात्र के लिए प्रयोग करें, जैसा कि निर्देश नियम-पुस्तिका में वर्णित किया गया है।
  यह उपकरण क्षीण शारीरिक, संवेदक या मानसिक क्षमताओं, या कम अनुभव एवं ज्ञान वाले व्यक्तियों (बच्चों सहित) के उपयोग हेतु नहीं बनाया गया है, बशर्ते उन्हें उनकी सुरक्षा के लिए किसी ज़िम्मेदार व्यक्ति द्वारा उपकरण के उपयोग संबंधी पर्यवेक्षण या निर्देश प्रदान किया गया हो।
- इस उपकरण का उपयोग 8 साल या उससे बड़े बच्चों तथा क्षीण शारीरिक, संवेदक या मानसिक क्षमताएँ या कम अनुभव एवं ज्ञान वाले व्यक्तियों द्वारा किया जा सकता है बशर्ते कि उन्हें उपकरण को सुरक्षित तरीके से उपयोग से जुड़े पर्यवेक्षण या निर्देश प्रदान किए गए हैं और वे इससे उत्पन्न ख़तरों को समझते हैं।
  बच्चों को उपकरण के साथ नहीं खेलने देना चाहिए।
  पर्यवेक्षण के बिना बच्चों को सफाई और उपयोगकर्ता रखरखाव नहीं करना चाहिए।
- इस नियम-पुस्तिका में चेतावनी एवं महत्वपूर्ण सुरक्षा निर्देशों में घटित हो सकने वाली सभी संभव परिस्थितियाँ तथा स्थितियाँ नहीं शामिल हैं।
  यह आपकी जिम्मेदारी है कि आप स्थापित, रखरखाव, तथा अपने उपकरण का संचालन करते समय सहज ज्ञान, सतर्कता एवं सावधानी का प्रयोग करें।

DA68-03194K-00.indb 2 2015. 5. 29. 2:21

- चूँकि ये संचालन निर्देश विभिन्न मॉडल पर लागू होते हैं, इसलिए आपके रेफ़्रिजरेटर की विशेषताएँ इस मार्गदर्शिका में वर्णित विशेषताओं से थोड़ी भिन्न हो सकती हैं और हो सकता है सभी चेतावनी चिह्न लागू न हों।
  रेफ़्रिजरेंट के रूप में R-600a या R-134a का उपयोग किया जाता है।
  आपके रेफ़्रिजरेटर के लिए उपयोग किए गए प्रशीतक का पता लगाने के लिए उपकरण के पिछले हिस्से में कंप्रेशर लेबल या फ़्रिज के अंदर रेटिंग लेबल देखें।
  चूँकि इस उत्पाद में ज्वलनशील गैस (रेफ़्रिजरेंट R-600a) मौजूद है, इसलिए इस उत्पाद के सुरक्षित निपटान के संबंध में स्थानीय प्राधिकरण से संपर्क करें।

- प्रशीतन सर्किट में रिसाव पाए जाने की स्थिति में ज्वलनशील गैस-वायु मिश्रण के निर्माण से बचने के लिए, उपकरण वाले कमरे का आकार प्रयुक्त प्रशीतक की मात्रा पर निर्भर हो सकता है।

- क्षति के लक्षण इंगित करने वाले उपकरण को कभी आरंभ न करें।
  अगर कोई शंका है, तो अपने डीलर से परामर्श लें।
  उपकरण के भीतर स्थित R-600a रेफ़्रिजरेंट के प्रत्येक 8 ग्राम के लिए स्थान का आकार 1 मी³ होना चाहिए।
  आपके व्यक्तिगत उपकरण में रेफ़्रिजरेंट की मात्रा उपकरण के भीतर लगी पहचान प्लेट पर दिखाई गई है।

- पाइपों से फुहार के रूप में बाहर छलकने वाले रेफ़्रिजरेंट के कारण आग लग सकती है या आँखों को चोट पहुँच सकती है।
  जब पाइप से रेफ़्रिजरेंट रिस रहा हो, तो अनावृत ज्वाला से बचें और किसी भी ज्वलनशील पदार्थ को उत्पाद से दूर ले जाएँ और कमरे में तुरंत हवा का संचार करें।

- ऐसा करने में विफल रहने पर आग लग सकती है या विस्फोट हो सकता है।

DA68-03194K-00.indb 3 2015. 5. 29. 2:21

महत्वपूर्ण सुरक्षा प्रतीक और सावधानियाँ:

चेतावनी	खतरे या असुरक्षित व्यवहार जिनसे **व्यक्तिगत रूप से गंभीर चोट लग सकती है या मृत्यु हो सकती है।**
सावधानी	खतरे या असुरक्षित व्यवहार जिनसे **व्यक्तिगत रूप से हल्की चोट लग सकती है या संपत्ति की क्षति हो सकती है।**

	इसका प्रयास न करें।
	इसे खोलें नहीं।
	इसे स्पर्श न करें।
	निर्देशों का सावधानीपूर्वक पालन करें।
	दीवार के सॉकेट से बिजली के प्लग को निकाल दें।
	बिजली के झटके से बचने के लिए सुनिश्चित करें की मशीन स्थिर है।
	सहायता के लिए संपर्क केंद्र पर कॉल करें।
	नोट।

ये चेतावनी संकेत आपको और दूसरों को चोट लगने से बचाने के लिए यहाँ मौजूद हैं।
कृपया उनका सावधानी से पालन करें।
इस खंड को पढ़ने के बाद, भावी संदर्भ के लिए उसे किसी सुरक्षित जगह पर रखें।

CE सूचना

इस उत्पाद द्वारा यूरोपीय संघ अधिनियम (EC) सं. 643/2009 द्वारा कार्यान्वित निम्न वोल्टेज निर्देश (2006/95/ EC), विद्युत-चुंबकीय संगतता निर्देश (2004/108/EC), RoHS निर्देश (2011/65/EU), आयोग प्रदत्त विनियम (EU) सं. 1060/2010 और पर्यावरण-प्रारूप निर्देश (2009/125/EC) के अनुपालन में निर्धारित हुआ है।
(केवल यूरोपीय देशों में बेचे गए उत्पादों के लिए)

DA68-03194K-00.indb 4 2015. 5. 29. 2:21

⚠ चेतावनी परिवहन और साइट के लिए गंभीर चेतावनी चिह्न

• उपकरण का परिवहन और स्थापना करते समय यह सुनिश्चित करने के लिए सावधानी बरती जानी चाहिए कि प्रशीतन सर्किट का कोई भाग क्षतिग्रस्त तो नहीं है।

- पाइप से रिसने वाले रेफ्रिजरेंट से आग लग सकती है या आँखों को चोट पहुँच सकती है। यदि रिसाव का पता लगता है, तो अग्नि या प्रज्वलन के संभावित स्रोत से बचें और उपकरण वाले कमरे में कुछ समय तक हवा आने दें।

- इस उपकरण में कम मात्रा में आइसोब्यूटेन रेफ्रिजरेंट (R-600a) शामिल होने पर भी यह गैस उच्च पर्यावरणीय संगतता वाली प्राकृतिक गैस है, यद्यपि यह ज्वलनशील भी होती है।
उपकरण के स्थानांतरण एवं स्थापना के दौरान प्रशीतन सर्किट के किसी भी भाग का क्षतिग्रस्त न होना सुनिश्चित करने के लिए सावधानी बरतनी चाहिए।

⚠ चेतावनी स्थापना के लिए गंभीर चेतावनी चिह्न

• विद्युतीय हिस्सों में खराब विद्युत-रोधन के कारण बिजली के झटके या आग लग सकती है।

• इस रेफ्रिजरेटर को सीधे सूर्यप्रकाश में न रखें या स्टोव, रूम हीटर या अन्य उपकरण की गर्मी से दूर रखें।

• एकाधिक पावर बोर्ड में अनेक उपकरणों के प्लग न लगाएँ।
रेफ्रिजरेटर का प्लग हमेशा अपने अलग बिजली के आउटलेट में लगा होना चाहिए जिसकी वोल्टेज रेटिंग, रेटिंग प्लेट से मेल खाती हो।

- इससे सर्वश्रेष्ठ कार्य-निष्पादन मिलता है और इससे घर का वायरिंग सर्किट ओवरलोड होने से भी बचता है, जिससे अत्यधिक गर्म तारों से आग का खतरा हो सकता है।

• यदि दीवार का सॉकेट ढीला हो, तो उसमें पावर प्लग न लगाएँ।

- इससे बिजली के झटके या आग का जोखिम होता है।

• ऐसे किसी तार का उपयोग न करें जिसकी पूरी लंबाई या किसी छोर में दरारें या घर्षण क्षति नजर आ रही हो।

DA68-03194K-00.indb 5 2015. 5. 29. 2:21

- बिजली के तार को खींचे या अधिक मोड़ें नहीं।
- बिजली के तार को मरोड़ें या बाँधें नहीं।
- बिजली के तार को धातु के पदार्थ पर न लटकाएँ, बिजली के तार पर कोई भारी पदार्थ न रखें, बिजली के तार को पदार्थों के बीच न डालें या बिजली के तार को उपकरण के पिछले हिस्से में न खींचें।

- रेफ्रिजरेटर का स्थान बदलने के दौरान, बिजली के तार को क्षतिग्रस्त न होने दें।
- इसके कारण बिजली का झटका या आग लग सकती है।

- रेफ्रिजरेटर के पास ऐरोसॉल्स का उपयोग न करें।
- रेफ्रिजरेटर के पास ऐयरोसोल्स का उपयोग करने से विस्फोट हो सकता है या आग लग सकती है।
- बिजली के तार को अधिक न मोड़ें या इस पर कोई भारी चीज न रख दें।

- यह रेफ्रिजरेटर उचित तरीके से स्थापित किया जाना चाहिए और उपयोग से पूर्व पुस्तिका के अनुसार अवस्थित होना चाहिए।

- रेफ्रिजरेटर को आर्द्रता वाले स्थान पर या किसी ऐसे स्थान पर स्थापित न करें जहाँ यह पानी के संपर्क में आ सकता हो।

- विद्युतीय हिस्सों में खराब विद्युत-रोधन के कारण बिजली के झटके या आग लग सकती है।

- तार को नीचे लटकाकर बिजली के प्लग को उचित स्थिति में कनेक्ट करें।
- अगर आप बिजली के प्लग को उल्टा लगाते हैं, तो तार कट सकता है और आग या बिजली का झटका लग सकता है।

- रेफ्रिजरेटर के पिछले हिस्से द्वारा बिजली के प्लग का कुचलना या क्षतिग्रस्त न होना सुनिश्चित करें।
- रेफ्रिजरेटर का स्थान बदलने के दौरान, बिजली के तार को क्षतिग्रस्त न होने दें।
- इससे आग का जोखिम हो सकता है।

- पैकिंग सामग्री को बच्चों की पहुँच से दूर रखें।
- अगर बच्चे उन्हें अपने सिर पर रखेंगे जो घुटन की वजह से मृत्यु होने का खतरा है।

- इस उपकरण को कुछ इस प्रकार लगाया जाना चाहिए कि यह बिजली के प्लग की पहुँच में हो।
- ऐसा करने में विफल रहने पर बिजली के रिसाव के कारण बिजली का झटका या आग लग सकती है।

- इस उपकरण को किसी हीटर, ज्वलनशील सामग्री के पास स्थापित न करें।

DA68-03194K-00.indb 6 2015. 5. 29. 2:21

- इस उपकरण को किसी नम, तेलीय या धूलयुक्त स्थान, किसी ऐसे स्थान पर न रखें जहाँ सीधा सूर्यप्रकाश और पानी (वर्षा की बूंदों) आता हो।
- इस उपकरण को किसी ऐसे स्थान पर स्थापित न करें जहाँ गैस रिस सकती हो।

- इसके कारण बिजली का झटका या आग लग सकती है।

- अगर रेफ़्रिजरेटर में धूल या पानी है, तो बिजली के प्लग को निकाल दें और अपने Samsung Electronics सेवा केंद्र से संपर्क करें।

- अन्यथा, आग लगने का जोखिम बना रहता है।

- उपकरण के ऊपर खड़े न हों या उपकरण पर वस्तुएँ (जैसे धुलने वाले कपड़े, जली मोमबत्ती, जली सिगरेट, थालियाँ, रसायन, धातु की वस्तुएँ आदि) न रखें।

- इससे बिजली का झटका, आग लग सकती है, उत्पाद में समस्याएँ हो सकती हैं या चोट लग सकती है।

- यह उपकरण ठीक प्रकार ग्राउंड किया गया होना चाहिए।

- उपकरण को गैस पाइप, प्लास्टिक के पानी के पाइप या टेलीफ़ोन लाइन से ग्राउंड न करें।

- बिजली के लीकेज को रोकने या रेफ़्रिजरेटर से वर्तमान लीकेज के कारण बिजली के झटके से बचने के लिए आपको रेफ़्रिजरेटर को ग्राउंड कर देना चाहिए।

- इससे बिजली का झटका, आग लग सकती है, विस्फोट हो सकता है या उत्पाद में समस्याएँ हो सकती हैं।

- बिजली के प्लग को कभी भी ऐसे सॉकेट में न लगाएँ जिसे ठीक प्रकार ग्राउंड नहीं किया गया है और सुनिश्चित करें कि यह स्थानीय और राष्ट्रीय संहिताओं के अनुपालन में है।

- यदि बिजली का तार क्षतिग्रस्त हो, तो इसे निर्माता या किसी सर्विस एजेंट द्वारा तत्काल बदलवाएँ।

- रेफ़्रिजरेटर पर लगा फ्यूज़ योग्य तकनीशियन या सर्विस कंपनी द्वारा ही बदला जाना चाहिए।

- ऐसा करने में विफल रहने पर बिजली का झटका या निजी चोट लग सकती है।

DA68-03194K-00.indb 7 2015. 5. 29. 2:21

⚠ सावधानी स्थापना के लिए सावधानी चिह्न

- उपकरण की अंदरूनी जगह या आधार संरचना में मौजूद वायुसंचार छिद्र में किसी भी तरह की रुकावट न आने दें।

- उपकरण की स्थापना के बाद खाद्य पदार्थ लोड करने और उपकरण को चालू करने से पहले 2 घंटे के लिए उसे खड़ा रखें।

- इस उपकरण की स्थापना या कोई भी सर्विस, योग्य तकनीशियन या सर्विस कंपनी से करने की अनुशंसा की जाती है।

- ऐसा करने में विफल रहने पर बिजली का झटका लग सकता है, आग लग सकती है, विस्फोट हो सकता है, उत्पाद में समस्याएँ हो सकती हैं या चोट लग सकती है।

- रेफ़्रिजरेटर को स्थापित करते समय, सुनिश्चित करें कि सुरक्षित स्थापना के लिए दोनों पाँव फ़र्श पर हों।
  पाँव फ़्रीज़र के दरवाज़े के निचले भाग के पीछे स्थित होते हैं।
  चपटे सिरे वाला स्क्रूड्राइवर का उपयोग करें और जब तक कि उसके पाँव बराबर नहीं हो जाते तीर की दिशा में घुमाते रहें।

- हमेशा दोनों दरवाज़ों के भार को बराबर रखें।

- किसी भी एक दरवाज़े पर अधिक भार होने से रेफ़्रिजरेटर गिर सकता है, जिसके कारण उसे क्षति पहुँच सकती है।

⚠ चेतावनी उपयोग के लिए गंभीर चेतावनी संकेत

- गीले हाथों से बिजली के प्लग को स्पर्श न करें।

- इसके कारण बिजली का झटका लग सकता है।

- उपकरण के शीर्ष पर सामान न रखें।

- जब आप दरवाजा खोलते या बंद करते हैं, तो सामान गिर सकते हैं तथा उससे व्यक्तिगत रूप से चोट लग सकती है और/या उपकरण क्षतिग्रस्त हो सकता है।

- पानी से भरे आइटम को रेफ़्रिजरेटर पर न रखें।

- इसके छलकने से आग या बिजली के झटके का खतरा हो सकता है।

- गीले हाथों से फ़्रीजर के अंदरूनी दीवारों या फ़्रीजर में रखे उत्पादों को न छुएँ।

- इससे शीतदंश हो सकता है।

- किन्हीं तापमान संवेदी पदार्थों जैसे ज्वलनशील स्प्रे, ज्वलनशील वस्तुएँ, सूखी बर्फ, दवाई या रसायनों का उपयोग रेफ़्रिजरेटर के पास न करें या इन्हें उसके पास न रखें।
  फ़्रिज में अस्थिर या ज्वलनशील वस्तुओं या पदार्थों (बेन्ज़ीन, थिनर, प्रोपेन गैस, अल्कोहल ईथर, LP गैस और ऐसे अन्य उत्पाद आदि) न रखें।

DA68-03194K-00.indb 8 2015. 5. 29. 2:21

- यह रेफ्रिजरेटर केवल भोजन के भंडारण के लिए है।

- इसके कारण आग लग सकती है या विस्फोट हो सकता है।

• रेफ्रिजरेटर में औषधीय उत्पाद, वैज्ञानिक सामग्रियाँ या तापमान-संवेदी उत्पाद न रखें।

- ऐसे उत्पादों को रेफ्रिजरेटर में नहीं रखा जाना चाहिए जिनके लिए सख्त तापमान नियंत्रणों की आवश्यकता होती है।

• रेफ्रिजरेटर/फ्रीजर के अंदर बिजली के उपकरण को न रखें या उनका उपयोग न करें, बशर्ते वे निर्माता द्वारा अनुशंसित श्रेणी के हों।

• अगर आपको औषधि या धूएँ की गंध आती है, तो तुरंत बिजली का प्लग निकाल दें और अपने Samsung Electronics सेवा केंद्र से संपर्क करें।

• अगर रेफ्रिजरेटर में धूल या पानी है, तो बिजली के प्लग को निकाल दें और अपने Samsung Electronics सेवा केंद्र से संपर्क करें।

- अन्यथा, आग लगने का जोखिम बना रहता है।

• अगर गैस रिसाव का पता लगता है, तो किसी भी अनावृत ज्वाला या ज्वलन के संभावित स्रोतों से बचें और जिस कमरे में उपकरण रखा है उसमें कई मिनट तक वायु का संचार करें।

• विहिमीकरण प्रक्रिया को तेज करने के लिए निर्माता द्वारा अनुशंसित मशीनी उपकरण या किसी दूसरे उपाय के बिना किसी अन्य उपकरण या उपाय का उपयोग न करें।

• प्रशीतक सर्किट को क्षति न पहुँचाएँ।

• उपकरण की सतह पर कीटनाशक जैसे ज्वलनशील पदार्थ का स्प्रे न करें।

- मानवों के लिए खतरनाक होने के साथ-साथ, इसके परिणामस्वरूप बिजली का झटका, आग लग सकती है या उत्पाद में समस्याएँ आ सकती हैं।

• रेफ्रिजरेटर के अंदरूनी हिस्से को सूखाने के लिए हेयर ड्रायर का उपयोग न करें। दुर्गंध हटाने के लिए रेफ्रिजरेटर के अंदर जलती मोमबत्ती न रखें।

- इसके कारण बिजली का झटका या आग लग सकती है।

• पानी के टैंक, बर्फ की ट्रे, पानी के क्यूब को केवल पीने योग्य पानी से ही भरें।

- चाय या स्पोर्ट्स ड्रिंक न भरे, इससे रेफ्रिजरेटर को क्षति पहुँच सकती है।

DA68-03194K-00.indb 9 2015. 5. 29. 2:21

- बच्चों को दरवाजे से लटकने न दें।
  अन्यथा, गंभीर चोट लग सकती है।

- बच्चों के फ़ंस जाने का खतरा।
  बच्चों को रेफ़्रिजरेटर के भीतर जाने नहीं दें।

- जब रेफ़्रिजरेटर के पास कोई न हो तो उसके दरवाज़ों को खुला न छोड़ें और बच्चों को रेफ़्रिजरेटर के भीतर प्रवेश न करने दें।

- शिशुओं और बच्चों को दराज के भीतर न जाने दें।

- इसके कारण फंसने की वजह से दम घुटने से मृत्यु हो सकती है या निजी चोट लग सकती है।

- फ़्रीज़र के दरवाज़े पर न बैठें।

- दरवाज़ा टूट सकता है और व्यक्तिगत रूप से चोट लग सकती है।

- यदि आपने ड्रॉअर से डिवाइडर को निकाल दिया हो, तो बच्चों के फ़ंस जाने से रोकने के लिए, आपको प्रदान किए गए स्कूज़ से सफ़ाई और अन्य क्रियाओं के बाद डिवाइडर को पुनः लगाएं।

- विहिमीकरण प्रक्रिया को तेज करने के लिए निर्माता द्वारा अनुशंसित मशीनी उपकरण या किसी दूसरे उपाय के बिना किसी अन्य उपकरण या उपाय का उपयोग न करें।

- प्रशीतक सर्किट को क्षति न पहुँचाएँ।

- गैस रिसाव (जैसे प्रोपेन गैस, LP गैस आदि) की स्थिति में, बिना बिजली के प्लग को छूए तत्काल हवा का प्रवाह करें।
  उपकरण या बिजली के तार को न छूएँ।

- किसी हवादार पंखे का उपयोग न करें।

- एक चिंगारी से विस्फोट या आग लग सकती है।

- केवल निर्माता या सर्विस एजेंट द्वारा प्रदान की गई LED लैंप का ही उपयोग करें।

- बच्चों की देखरेख की जानी चाहिए ताकि उनका उपकरण के साथ न खेलना सुनिश्चित किया जा सके।

- उंगलियों को “पिंच-पॉइंट” क्षेत्रों से दूर रखें, दरवाज़ों और कैबिनेट के बीच का स्थान बहुत छोटा होता है।

- बच्चों को दरवाजे से लटकने न दें।
  अन्यथा, गंभीर चोट लग सकती है।

- बच्चों के फंसने का खतरा होता है।
  बच्चों को रेफ़्रिजरेटर के भीतर जाने नहीं दें।

- बोतलों को एकदम सटाकर रखना चाहिए ताकि वे गिर न जाएँ।

DA68-03194K-00.indb 10 2015. 5. 29. 2:21

- यह उत्पाद घरेलू परिवेश में केवल खाद्य पदार्थ के भंडारण के लिए नियत है।
- उंगलियों या अन्य वस्तुओं को डिस्पेंसर छिद्र, बर्फ़ के शूट, और बर्फ बनाने वाली बकेट में न रखें।
- इससे व्यक्तिगत रूप से चोट लग सकती है या सामग्री की क्षति हो सकती है।
- हाथों, पैरों या धातु की वस्तुओं (जैसे चॉपस्टिक, आदि) को रेफ़्रिजरेटर के निचले या पिछले भाग में न डालें।
- इसके कारण बिजली का झटका या चोट लग सकती है।
- किसी भी नुकीले किनारे से व्यक्तिगत रूप से चोट लग सकती है।

- स्वयं उपकरण की मरम्मत, उसे खोलने या संशोधित करने का प्रयास न करें।
- मानक फ्यूज़ के अलावा किसी अन्य फ्यूज़ (जैसे ताँबे, स्टील के तार, आदि) का उपयोग न करें।
- जब उपकरण की मरम्मत या पुनः स्थापना की आवश्यकता हो, तो अपने निकटतम सेवा केंद्र से संपर्क करें।
- ऐसा करने में विफल रहने पर बिजली का झटका, आग लग सकती है, उत्पाद में समस्याएँ हो सकती हैं या चोट लग सकती है।

- अगर उपकरण अजीब आवाज़, जलन या गंध या धुआँ पैदा करता है, तो तत्काल बिजली प्लग निकालें और अपने निकटतम सेवा केंद्र से संपर्क करें।
- ऐसा करने में विफल रहने पर बिजली या आग के जोखिम हो सकते हैं।
- रेफ़्रिजरेटर के अंदरुनी लैंप को बदलने से पहले पावर प्लग को सॉकेट से बाहर निकाल लें
- अन्यथा, बिजली के झटके का जोखिम बना रहता है।
- यदि आप लाइट बदलने में परेशानी महसूस करते हैं, तो सर्विस एजेंट से संपर्क करें।
- अगर उत्पादों में LED लैंप लगी हैं, तो स्वयं लैंप कवर या LED लैंप को न खोलें।
- कृपया अपने सर्विस एजेंट से संपर्क करें।
- पावर प्लग को वॉल सॉकेट में ठीक से लगाएँ। खराब पावर प्लग, पावर कॉर्ड या ढीले वॉल सॉकेट का उपयोग न करें।
- इसके कारण बिजली का झटका या आग लग सकती है।

DA68-03194K-00.indb 11 2015. 5. 29. 2:21

• पानी से भरे पात्र को उपकरण पर न रखें।

- इसके छलकने से आग या बिजली के झटके का खतरा हो सकता है।

• UV LED लैंप को लंबे समय तक सीधे न घूरें।

- इससे पराबैंगनी किरणों के कारण आँखों को नुकसान हो सकता है।

⚠ सावधानी उपयोग के लिए सावधानी संकेत

• उत्पाद से सर्वश्रेष्ठ कार्य-निष्पादन पाने के लिए,

- खाद्य पदार्थों को उपकरण के पिछले भाग में निकासों के सामने बहुत पास न रखें क्योंकि इससे रेफ्रिजरेटर कंपार्टमेंट में स्वतंत्र वायु संचार बाधित हो सकता है।

- भोजन को रेफ्रिजरेटर में रखने से पहले उचित तरीके से ढकें या किसी वायुरुद्ध पात्र में रखें।

- तुरंत बनाए गए भोजन को फ्रीज़ करने के लिए पहले से मौजूद भोजन के पास न रखें।

• ग्लास या बोतल या कार्बोनेट किए गए पेय-पदार्थों को फ्रीजर में न रखें।

- पात्र जम या टूट सकता है और इससे चोट लग सकती है।

• कृपया जमे हुए सामानों के अधिकतम संग्रहण समय और समाप्ति तिथियों का ध्यान रखें।

• रेफ्रिजरेटर में तापमान-संवेदी औषधीय उत्पाद, वैज्ञानिक सामग्रियाँ या अन्य तापमान-संवेदी उत्पाद न रखें।

- ऐसे उत्पादों को रेफ्रिजरेटर में नहीं रखा जाना चाहिए जिनके लिए सख्त तापमान नियंत्रणों की आवश्यकता होती है।

• अगर आप तीन सप्ताह से कम समय के लिए बाहर हैं तो रेफ्रजरेटर को बिजली आपूर्ति से डिस्कनेक्ट करने का आवश्यकता नहीं है।
लेकिन, अगर आप तीन सप्ताह या अधिक समय के लिए बाहर जा रहे हैं तो सभी भोजन को निकाल दें।
रेफ्रिजरेटर का प्लग निकालें और इसकी सफाई, धुलाई करें और सुखाएँ।

• कार्बोनेट युक्त या गैस युक्त पेय पदार्थों को फ्रीजर कंपार्टमेंट में न रखें।
बोतल या काँच के पात्रों को फ्रीजर में न रखें।

- जब अंदर रखा पदार्थ जम जाता है, तो काँच टूट सकता है और निजी चोट लग सकती है और संपत्ति को क्षति हो सकती है।

DA68-03194K-00.indb 12 2015. 5. 29. 2:21

- रेफ्रिजरेटर को रूपांतरित न करें। अनधिकृत रूपांतरण से सुरक्षा संबंधी समस्याएँ हो सकती हैं। अनधिकृत रूपांतरण को पूर्णतया पलटने के लिए, हम पार्ट्स और श्रम की पूरी लागत लेंगे।
- रेफ्रिजरेटर की कार्यक्षमता को परिवर्तित या संशोधित न करें।

- परिवर्तनों या संशोधनों से निजी चोट और/या संपत्ति को क्षति हो सकती है।
  इस पूर्ण उपकरण पर तृतीय पक्ष द्वारा किया गया कोई भी परिवर्तन या संशोधन न तो Samsung वारंटी सेवा में शामिल है और न ही तृतीय पक्ष के संशोधनों से होने वाली सुरक्षा समस्याओं और क्षतियों के लिए Samsung ज़िम्मेदार है।

- वायु छिद्रों को अवरोधित न करें।

- अगर वायु छिद्र अवरोधित हो जाते हैं, विशेष रूप से प्लास्टिक बैग से, तो रेफ्रिजरेटर आवश्यकता से अधिक ठंडा हो सकता है।
  अगर कूलिंग अवधि बहुत देर तक बनी रहती है, तो पानी का फ़िल्टर टूट सकता है और पानी रिस सकता है।

- केवल रेफ्रिजरेटर के साथ प्रदान किए गए आइस-मेकर का उपयोग करें।
- इस रेफ्रिजरेटर की पानी की आपूर्ति किसी उपयुक्त योग्य व्यक्ति द्वारा ही स्थापित / कनेक्ट की जानी चाहिए और यह केवल पीने योग्य पानी की आपूर्ति से कनेक्ट होनी चाहिए।
- अगर आप लंबी छुट्टियों या व्यावसायिक यात्रा पर जा रहे हैं और उस दौरान पानी या बर्फ़ डिस्पेंसर का उपयोग नहीं करेंगे, तो पानी के वाल्व को बंद कर दें।

- अन्यथा, पानी का रिसाव हो सकता है।

- भीतर से अधिक नमी को पोंछ दें और दरवाज़ों को खुला छोड़ दें।

- अन्यथा, दुर्गंध और फफूँद उत्पन्न हो सकती है।

- जब रेफ्रिजरेटर पानी से भीग जाए, तो बिजली के प्लग को निकाल दें और अपने Samsung Electronics सेवा केंद्र से संपर्क करें।
- काँच की सतह पर तेज़ झटका या अत्यधिक बल न लगाएँ।

- टूटे काँच से निजी चोट और/या संपत्ति को क्षति हो सकती है।

- दरवाज़े पर या रेफ्रिजरेटर के होम बार पर बैठें या लटकें नहीं।

DA68-03194K-00.indb 13 2015. 5. 29. 2:21

- इससे रेफ़्रिजरेटर आपके ऊपर गिर सकता है, दरवाज़ा अलग हो सकता है या हाथ दरवाज़े की दरार में फ़ंस सकता है और इससे संपत्ति को क्षति पहुँच सकती है या चोट लग सकती है।

• यदि बिजली की तार खराब हो, तो जोखिम से बचने के लिए इसे निर्माता, इसके सेवा एजेंट या समान रूप से योग्य व्यक्ति द्वारा बदला जाना चाहिए।

⚠ सावधानी सफाई और रखरखाव के लिए सावधानी संकेत

• प्रदर्शन पर सफाई उत्पादों को सीधे स्प्रे न करें।

- प्रदर्शन पर लगे मुद्रित पत्र छूट सकते हैं।

• अगर कोई बाहरी पदार्थ जैसे पानी उपकरण में प्रवेश कर गया है, तो बिजली के प्लग को निकाल दें और अपने निकटतम सेवा केंद्र से संपर्क करें।

- ऐसा करने में विफल रहने पर बिजली का झटका या आग लग सकती है।

• नियमित रूप से एक सूखे कपड़े का उपयोग करके बिजली के प्लग के टर्मिनल और संपर्क बिंदुओं से धूल या पानी जैसे सभी बाहरी पदार्थों को निकाल दें।

- बिजली के प्लग को निकालें और इसे सूखे कपड़े से साफ करें।

- ऐसा करने में विफल रहने पर बिजली का झटका या आग लग सकती है।

• उपकरण पर सीधे पानी का स्प्रे करके उसे साफ न करें।

• सफाई के लिए बेंजीन, थिनर, या क्लोरोक्स, क्लोराइड का उपयोग न करें।

- वे उपकरण की सतह को क्षति पहुँचा सकते हैं और आग लगा सकते हैं।

• सफाई या रखरखाव करने से पहले, उपकरण का प्लग दीवार के सॉकेट से निकाल दें।

- ऐसा करने में विफल रहने पर बिजली का झटका या आग लग सकती है।

DA68-03194K-00.indb 14 2015. 5. 29. 2:21

चेतावनी निपटान के लिए गंभीर चेतावनी संकेत

- शेल्फ़ को ऐसे स्थान पर रखें ताकि बच्चे आसानी से भीतर न चढ़ पाएँ।

- निपटान से पहले सुनिश्चित करें कि उपकरण के पीछे लगा कोई पाइप क्षतिग्रस्त नहीं है।

- रेफ्रिजरेंट के रूप में R-600a या R-134a का उपयोग किया जाता है।
  आपके रेफ्रिजरेटर के लिए उपयोग किए गए प्रशीतक का पता लगाने के लिए उपकरण के पिछले हिस्से में कंप्रेशर लेबल या फ्रिज के अंदर रेटिंग लेबल देखें।
  चूँकि इस उत्पाद में ज्वलनशील गैस (रेफ्रिजरेंट R-600a) मौजूद है, इसलिए इस उत्पाद के सुरक्षित निपटान के संबंध में स्थानीय प्राधिकरण से संपर्क करें। रोधन को उड़ाने वाली गैस के रूप में साइक्लोपेंटेन का उपयोग किया गया है।
  रोधन सामग्री में स्थित गैसों के निपटान के लिए विशेष निपटान प्रक्रिया की आवश्यकता होती है।
  इस उत्पाद के पर्यावरण की दृष्टि से सुरक्षित निपाटन के संबंध में अपने स्थानीय प्राधिकरणों से संपर्क करें।
  निपटान से पहले सुनिश्चित करें कि उपकरण के पीछे लगे कोई पाइप क्षतिग्रस्त नहीं है।
  पाइपों को खुले स्थान पर तोड़ा जाना चाहिए।

- अंदर फँसने पर बच्चों को चोट लग सकती है और दम घुटने से मृत्यु हो सकती है।

- कृपया इस उत्पाद की पैकेजिंग सामग्री का निपटान पर्यावरण-अनुकूल तरीके से करें।

- सभी पैकेजिंग सामग्रियों को बच्चों की पहुँच से दूर रखें, क्योंकि पैकेजिंग सामग्री बच्चों के लिए खतरनाक हो सकती है।

- अगर बच्चा किसी बैग को अपने सिर पर रख लेता है, तो उसका दम घुट सकता है।

DA68-03194K-00.indb 15 2015. 5. 29. 2:21

उचित उपयोग के लिए अतिरिक्त युक्तियाँ

- बिजली चले जाने की स्थिति में अपनी बिजली कंपनी के स्थानीय कार्यालय में कॉल करें और पूछें कि यह कब तक आएगी।
- एक या दो घंटो में सुधार ली जाने वाली बिजली विफलताओं से आपके रेफ्रिजरेटर पर कोई प्रभाव नहीं पड़ता है।
  हालाँकि, बिजली न होने पर आपको दरवाज़ा बार-बार नहीं खोलना चाहिए।
- लेकिन अगर बिजली 24 घंटे से अधिक समय तक नहीं आती है, तो सभी जमे भोजन को निकाल दें।
- अगर रेफ्रिजरेटर के साथ चाबियाँ प्रदान की गई हैं, तो चाबियों को बच्चों की पहुँच से दूर रखना चाहिए और इन्हें उपकरण के पास नहीं छोड़ना चाहिए।
- जब उपकरण को अधिक समय तक उस तापमान की सीमा के अंतिम शीत बिंदु पर चलाया जाता है, तो हो सकता है कि उपकरण संगत रूप से (सामग्रियों के विहिमीकरण की संभावना या जमे भोजन के कंपार्टमेंट में तापमान बहुत गर्म होना) कार्य न करे।
- विशेष खाद्य पदार्थों के मामले में, उन्हें प्रशीतन के तहत रखने से उनके गुणों के संरक्षण पर बुरा असर हो सकता है।
- आपका उपकरण तुषार मुक्त है, जिसका अर्थ है कि अपने उपकरण को मैन्युअल रूप से विहिमीकृत करने की आवश्यकता नहीं है, क्योंकि यह स्वचालित रूप से हो जाएगा।
- विहिमीकरण के दौरान तापमान का बढ़ना ISO आवश्यकताओं के अनुपालन में हो सकता है। लेकिन अगर आप उपकरण के विहिमीकरण के दौरान जमें हुए भोजन के तापमान में अनावश्यक वृद्धि से बचना चाहते हैं, तो कृपया जमे हुए भोजन को समाचारपत्रों की कई परतों में लपेट दें।
- विहिमीकरण के दौरान जमे भोजन के तापमान में किसी भी प्रकार की वृद्धि से उसका संग्रहण समय कम हो सकता है।
- उन जमे भोजनों को फिर न जमाएँ जो पूरी तरह पिघल चुकें हैं।
- क्योटो प्रोटोकॉल द्वारा कवर किए जा रहे फ्लोरिनेटेड ग्रीनहाउस गैस समाविष्ट हैं।
  फ्लोरिनेटेड ग्रीनहाउस गैस से झाग उड़ाया गया।
  झाग उड़ाने हेतु योज्य: परफ़्लोरोहेक्सेन
  भूमण्डलीय तापक्रम वृद्धि संभावना
  (GWP) = 9300

DA68-03194K-00.indb 16 2015. 5. 29. 2:21

बिजली की बचत करने की युक्तियाँ

- उपकरण को पर्याप्त हवा वाले एक ठंडे, सूखे कमरे स्थापित करें।
  सुनिश्चित करें कि यह सीधे सूर्य के प्रकाश के संपर्क में नहीं आ रहा है और कभी भी इसे गर्मी के प्रत्यक्ष स्रोत (उदाहरण के लिए रेडिएटर) के पास न रखें।
- ऊर्जा दक्षता के लिए किसी निकास द्वारा और ग्रिल को अवरुद्ध न करने की सिफ़ारिश की जाती है।
- गर्म भोजन को उपकरण में रखने से पहले भोजन को ठंडा होने दें।
- पिघलाने के लिए जमे हुए भोजन को रेफ़्रिजरेटर में रखें।
  तब आप रेफ़्रिजरेटर में भोजन को ठंडा करने के लिए जमे उत्पादों के निम्न तापमानों का उपयोग कर सकते हैं।
- भोजन रखते या बाहर निकालते समय उपकरण के दरवाज़े को बहुत देर तक खोलकर न रखें।
  आप जितने कम समय के लिए दरवाज़ा खोलेंगे, फ़्रीजर में उतनी कम बर्फ जमेगी।
- इंस्टॉल करते समय दाएं, बाएं, पीछे और ऊपर खाली स्थान छोड़ें।
  इससे बिजली की खपत को कम करने और आपके बिजली की बिलों को कम बनाए रखने में मदद मिलेगी।
- ऊर्जा के सबसे प्रभावी उपयोग के लिए, कृपया भीतर की सभी फिटिंग जैसे टोकरी, दराज, शेल्फ़ को उसी स्थान पर रखें जैसा निर्माता द्वारा आपूर्ति किया गया है।

यह उपकरण केवल घरेलू या इसी प्रकार के स्थानों पर उपयोग किए जाने के लिए बनाया गया है, जैसे कि

- दुकानों, कार्यालयों और अन्य कार्यस्थलों में कर्मचारियों के लिए बने रसोईघरों में;
- फ़ार्म हाउस में और होटलों, मोटलों और अन्य आवासीय स्थानों पर क्लाइंट द्वारा;
- विश्राम और खान-पान वाले परिवेश में;
- केटरिंग और इसी प्रकार के गैर-खुदरा स्थानों पर।

DA68-03194K-00.indb 17 2015. 5. 29. 2:21

अपने रेफ्रिजरेटर को सेट करना

रेफ्रिजरेटर को स्थापित करने के लिए तैयार होना

Samsung रेफ्रिजरेटर खरीदने पर आपको बधाई।
हम आशा करते हैं कि आप बहुत सी अत्याधुनिक सुविधाओं और क्षमताओं का आनंद लेंगे जो यह नया उपकरण आपको प्रदान करेगा।

रेफ्रिजरेटर के लिए सर्वोत्तम स्थान का चयन करना

यह चुनें :

- ऐसा स्थान, जहाँ पानी की आपूर्ति आसानी से हो सके।
- ऐसा स्थान, जहाँ सूर्य का प्रकाश सीधा न पड़ता हो।
- समतल (या लगभग समतल) सतह वाला स्थान।
- ऐसा स्थान, जहाँ रेफ्रिजरेटर के दरवाज़े आसानी से खुल सकें।
- ऐसा स्थान,जहाँ दाएँ, बाएँ, पीछे और ऊपर वायु के प्रवाह के लिए पर्याप्त स्थान हो।
  यदि रेफ्रिजरेटर में पर्याप्त स्थान न हो, तो इससे रेफ्रिजरेटर की कार्यक्षमत और पावर खपत पर गलत प्रभाव पड़ सकता है।
- ऐसा स्थान, जहाँ रखरखाव या सर्विस की आवश्यकता पड़ने पर आप रेफ्रिजरेटर को आसानी से घुमा सकें।
- रेफ्रिजरेटर को ऐसे स्थान पर स्थापित न करें जहाँ तापमान 43 °C से अधिक या 5 °C से कम हो।



गहराई "A"	733 मिमी
चौड़ाई "B"	908 मिमी
ऊँचाई "C"	1797 मिमी
संपूर्ण ऊँचाई "D"	1825 मिमी





- प्रत्येक माप डिज़ाइन के आयाम पर आधारित होता है, इसलिए मापन विधि के आधार पर उसमें भिन्नता हो सकती है।

DA68-03194K-00.indb 18 2015. 5. 29. 2:21

अपने रेफ़्रिजरेटर को स्थानांतरित करते समय

सतह को क्षतिग्रस्त होने से बचाने के लिए, सुनिश्चित करें कि आगे के समतल करने वाले पाये ऊपरी (सतह से ऊपर) दिशा में हैं।
इस मार्गदर्शिका में पृष्ठ 23 पर दिए "रेफ़्रिजरेटर को समतल करने के तरीके" देखें।

सतह

उचित स्थापना के लिए, रेफ़्रिजरेटर को ऐसी समतल, ठोस सतह पर रखा जाना चाहिए जिसकी ऊँचाई बाकी सतह के समान हो।
यह सतह पूरी तरह से भरे रेफ़्रिजरेटर का समर्थन करने में सक्षम होनी चाहिए।
तल की फ़िनिश को सुरक्षित करने के लिए, कार्डबोर्ड के डब्बे का एक बड़ा भाग काटें और उसे रेफ़्रिजरेटर के नीचे उस स्थान रखें जहाँ आप काम कर रहे हैं।
अपने रेफ़्रिजरेटर को स्थानांतरित करते समय, आपको उसे सीधे आगे या पीछे खींचना होगा।
इसे एक तरफ से दूसरी तरफ न हिलाएँ।



रेफ़्रिजरेटर के दरवाज़े निकालना

यदि रेफ़्रिजरेटर आपके दरवाज़ों से आसानी से निकलने में बहुत बड़ा हो, तो आप रेफ़्रिजरेटर के दरवाज़े खोल सकते हैं।

आपके लिए आवश्यक उपकरण

		
फ़िलिप्स पेचकस (+)	फ़्लैट-ब्लेड स्क्रूड्राइवर (-)	सॉकेट रिंच 10 मिमी
पिलर्स	एलन रिंच (4 मिमी)	एलन रिंच (5 मिमी)

सावधानी

- दरवाज़े और ड्रॉवर निकालने के पहले रेफ़्रिजरेटर का पावर डिस्कनेक्ट कर दें।

- दरवाज़ों/ड्रॉवर को निकालते समय उन्हें नीचे गिरने से बचाने की सावधानी रखें।

- दरवाज़ों/ड्रॉवर को निकालते समय सावधानी का उपयोग करें। दरवाज़े भारी हैं और आपको चोट लग सकती है।
- इनसे बचने के लिए दरवाज़ों/ड्रॉवर को पुनः लगाएं:
- वायु रिसाव से नमी।
- दरवाज़े का असमान संरेखण।
- अनुपयुक्त डोर सील के कारण ऊर्जा व्यर्थ होना।

DA68-03194K-00.indb 19 2015. 5. 29. 2:21

फ़्रिज डोर को अलग कर दें

1. दरवाज़े को बंद रखकर, किसी फ़िलिप्स (+) स्क्रूड्राइवर द्वारा शीर्ष कवर (A) को पकड़े रखने वाले 3 स्क्रू निकालें और फिर लगाए गए संपूर्ण वायर हार्नेस के साथ शीर्ष कवर निकालें।



2. बाएं दरवाज़े पर लगे दोनों वायर हार्नेस और दाएं दरवाज़े पर लगे एक वायर हार्नेस को डिस्कनेक्ट करें।
(यह मॉडल के आधार पर भिन्न हो सकता है।)



3. प्रथम लीवर (B) को खींचें, और फिर उसे आगे खींचें।



4. कब्जा (C) निकालें।



5. फ़्रिज के दरवाज़े को ऊपर उठाएं और उसे बाहर निकालें।

सावधानी
- दरवाज़े को अलग करने और फिर से लगाने के दौरान, यह सुनिश्चित करें कि विद्युत वायर छिल न जाएं।
- दरवाज़े को गिरने न दें।

फ़्रीज़र के दरवाज़ों को अलग करें

सावधानी
- फ़्रीज़र के दरवाज़े को निकालने से पहले फ़्रिज का दरवाज़ा निकालना सुनिश्चित करें।
- अलग करते समय फ़्रीज़र के दरवाज़े के निचले भाग से संलग्न वायर से सावधान रहें।

1. दरवाज़ा खुला रखकर, किसी फ़िलिप्स स्क्रूड्राइवर (+) द्वारा समायोजित किए जा सकने वाले पांव के कवर (A) को पकड़े रखने वाले स्क्रू को निकालें और फिर कनेक्टर (B) को निकालें।



2. फ़्रीज़र के दरवाज़े के ऊपर स्थित दरवाज़े के कब्जे पर मध्य कब्जा कैप (C) को ऊपर उठाएं और निकालें।



DA68-03194K-00.indb 20 2015. 5. 29. 2:21

3. तीर की दिशा में दरवाज़े को धकाते हुए मध्य कब्जा शॉफ़्ट (D) को ऊपर उठाएं।



4. यह सावधानी रखते हुए कि दरवाज़ा मध्य कब्जे (E) को स्पर्श न करे, दरवाज़े को थोड़ा आगे की ओर झुकाएं और फिर उसे निकालने के लिए ऊपर उठाएं।



रेफ़्रिजरेटर के दरवाज़े लगाना

सावधानी

- फ़्रिज के दरवाज़े को पुनः लगाने से पहले फ़्रीज़र का दरवाज़ा पुनः लगाना सुनिश्चित करें।

- पुनः लगाने से पहले, सुनिश्चित करें कि फ़्रीज़र के दरवाज़े के नीचे लगे सभी तार के कनेक्टर कनेक्ट हैं।

फ़्रीज़र का दरवाज़ा पुनः लगाने का तरीका

1. दरवाज़े को निचले कब्जे (A) में (1) की दिशा में डालें और फिर दरवाज़े को (2) की दिशा में धकेलें।
   मध्य-कब्जे (B) से दरवाज़े पर खरोंच न लगने की सावधानी रखें (B)।



सावधानी

- दरवाज़ों के निचले हिस्से पर मौजूद वायर के क्षतिग्रस्त न होने का ध्यान रखें।
  उन पर चढ़ने इत्यादि से बचें।

2. कब्जा शॉफ़्ट (C) को मध्य कब्जे के छिद्र (D) में डालें और कब्जे की कैप (E) लगाएं।

- कब्जा शॉफ़्ट और कब्जा कैप लगाते समय यह सुनिश्चित करें कि वे सही दिशा में लगाई जाएं।



3. दरवाज़ा खुला रखकर, कनेक्टर्स को दरवाज़े के निचले हिस्से में जोड़ें।



- कनेक्टर्स पर खड़े न होने या उन्हें क्षतिग्रस्त न करने की सावधानी रखें।

4. समायोजित किए जा सकने वाले पांव के कवर को फ़िलिप्स (+) स्क्रूड्राइवर का उपयोग करके अटैच करें।



DA68-03194K-00.indb 21 2015. 5. 29. 2:21

फ़्रीज़ का दरवाज़ा पुनः लगाने का तरीका

1. फ़्रिज के अलग किए गए दरवाज़े को मध्य कब्जे पर लगाएं।

2. फ़्रिज के कब्जे (A) को फ़िक्सिंग स्लॉट में स्लाइड करें और फिर उसे नीचे की ओर दबाएं ताकि वह दरवाज़े के छिद्र से संरेखित हो जाए।



3. फ़िक्स्ड लीवर (B) को तीर की दिशा में डालें और फिर उसे लगाने के लिए नीचे फ़्लिप करें।



4. वायर कनेक्टर लगाएं।



5. शीर्ष कवर के अगले भाग को लगाएं और फिर उसके पिछले भाग को तब तक नीचे दबाएं जब तक कि वह समतल न लग जाए।
स्क्रू को पुनः लगाए।



सावधानी

- दरवाज़े को इसे निकालने के विपरीत क्रम में लगाएँ। यह फ़्रीज़ और फ़्रीज़र के दरवाज़े दोनों के लिए समान है।
- जब वायर कनेक्टर्स क्रॉस असेम्बल किए जा रहे हों, तो हो सकता है कि डिस्प्ले सामान्य तरीके से कार्य न करे।

DA68-03194K-00.indb 22 2015. 5. 29. 2:21

रेफ़्रिजरेटर को समतल करना और ऊँचाई और दरवाज़ों के अंतर को समायोजित करना

रेफ़्रिजरेटर को समतल कैसे करें

रेफ़्रिजरेटर की अस्थिरता के कारण होने वाले खतरों से बचने के लिए, कृपया रेफ़्रिजरेटर को क्षैतिज सपोर्ट पर रखें और उसे स्थापना के निम्नलिखित निर्देशों के अनुसार समतल रखें।
ऐसा करने में विफल रहने के परिणामस्वरूप रेफ़्रिजरेटर पलट सकता है और चोट लग सकती है।
यदि उपकरण का सामने का भाग, पिछले भाग से थोड़ा सा ऊँचा हो, तो दरवाज़े को अधिक आसानी से खोला और बंद किया जा सकता है।
रेफ़्रिजरेटर को असमान समतल पर सेट अप करने पर रेफ़्रिजरेटर अस्थिर हो सकता है।

- रेफ़्रिजरेटर को स्थापित करते समय उसके पांव सतह के स्पर्श में निश्चित रूप से होने चाहिए।
  पांव प्रत्येक दरवाज़े के निचले भाग के पीछे होने चाहिए।
  इसे फ़्लैटहेड स्क्रूड्राइवर से डालें और तीर की दिशा में कसें।

यदि रेफ़्रिजरेटर को ऐसी सतह पर रखा गया है, जो समतल नहीं है, तो इससे दरवाज़ों के बीच ऊंचाई का अंतर उत्पन्न हो सकता है।

- लेवलिंग लेग कंट्रोल लीवर के स्लॉट में एक फ़्लैट हेड (-) स्क्रूड्राइवर डालें और कंट्रोल लीवर को घड़ी की दिशा में या घड़ी की विपरीत दिशा में घुमाते हुए स्तर को समायोजित करें।
  जब आप लीवर को घड़ी की दिशा में घुमाते हैं, तो आप रेफ़्रिजरेटर को उठाते हैं।
  जब आप लीवर को घड़ी की विपरीत दिशा में घुमाते हैं, तो आप रेफ़्रिजरेटर को नीचे करते हैं।



- यदि रेफ़्रिजरेटर पीछे और आगे से समान स्तर पर नहीं है, तो कोई ठोस पैनल (जैसे कोई प्लास्टिक पैनल, कोई प्लास्टिक रूलर इत्यादि) को सतह पर रखें, जिस पर पिछले पांव जम सकें, और फिर उसे उस स्थान पर प्लास्टिक टेप से लगा दें।
  जब आप रेफ़्रिजरेटर को अंदर धकेलते हैं, तो यह सुनिश्चित करें कि इसके पिछले पाँव पैनल पर टिके हों।

- यदि आपके पास कोई लकड़ी की सतह या समान नर्म सतह है, तो रेफ़्रिजरेटर को इसके स्थान पर धकेलते समय सतह के क्षतिग्रस्त न होने की सावधानी रखें।

DA68-03194K-00.indb 23 2015. 5. 29. 2:21

दरवाज़े की ऊँचाई समायोजित करने का तरीका

यदि दरवाज़ों में से कोई भी, अन्य से निचले स्तर पर हो:



- यह जांच करें कि क्या दरवाज़े को समायोजित करने के पहले रेफ़्रिजरेटर को समान स्तर पर रखा गया है।
- दरवाज़े की ऊंचाई के अंतर को दिखाए अनुसार दरवाज़े और कब्जे के बीच स्नैप रिंग (1) डालकर समायोजित करें।
  आप फ़्रेश फूड कंपार्टमेंट की दाईं ओर के दरवाज़े पर और फ़्रीज़र कंपार्टमेंट के दोनों ओर रिंग्स का उपयोग कर सकते हैं।



- ऊंचाई के अंतर की जांच करने के बाद, उपयुक्त मोटाई वाली एक स्नैप रिंग का चयन करें। केवल एक स्नैप रिंग डालें, दो या इससे अधिक स्नैप रिंग डालने से स्नैप रिंग फिसल सकती हैं या रगड़ की आवाज़ हो सकती है।
- निचले दरवाज़े को ऊपर उठाएं और दरवाज़े और कब्जे के बीच के स्थान में स्नैप रिंग डालें।

सावधानी
- चोट लगने से बचने के लिए, स्नैप रिंग्स को सावधानीपूर्वक डालें या निकालें।
- स्नैप रिंग्स को बच्चों की पहुँच से दूर रखें और सुनिश्चित करें कि बच्चे उनके साथ न खेलें या उन्हें अपने मुँह में न डालें।

- रेफ़्रिजरेटर के साथ 1 मिमी, 1.5 मिमी, 2 मिमी, और 2.5 मिमी स्नैप रिंग्स आती हैं।
- यदि रेफ़्रिजरेटर को भोजन से लोड करने से पहले समान स्तर पर नहीं रखा जाता है, तो वह भोजन के वज़न के कारण असंतुलित हो सकता है। यदि ऐसा होता है तो समान प्रक्रिया का उपयोग करके स्तर को पुनः समायोजित करें।
- यदि आप दरवाज़े को बहुत ऊँचा उठाते हैं, तो इस पर शीर्ष कवर से रगड़ लग सकती है।

रेफ़्रिजरेटर के साथ सम्मिलित की गई स्नैप रिंग्स:

दरवाज़ों के अंतर को समायोजित करने का तरीका

यदि बाएं और दाएं फ़्रिज कंपार्टमेंट दरवाज़ों का के बीच का अंतर समान नहीं है।



- आप कोल्ड स्टोरेज कंपार्टमेंट दरवाज़े के ऊपर दाएं स्थित बोल्ट को घुमा कर अंतर को समायोजित कर सकते हैं।
- बोल्ट को बहुत अधिक न घुमाएं। हो सकता है कि यह टूट जाए।

1. दरवाज़ों को बंद रखकर, किसी फ़िलिप्स (+) स्क्रूड्राइवर का उपयोग करके शीर्ष कवर (A) को पकड़े रखने वाले 3 स्क्रू निकालें और फिर कनेक्ट की गई केबल्स के साथ उसे एक साथ ऊपर उठाएं।



2. अंतर को समायोजित करने के लिए बोल्ट को किसी 4 मिमी हेक्सागोनल L-रेंच से घुमाएं।



3. अंतर को बढ़ाने के लिए बोल्ट को घड़ी की दिशा में ( ) घुमाएं। अंतर को कम करने के लिए बोल्ट को घड़ी की विपरीत दिशा में ( ) घुमाएं।

DA68-03194K-00.indb 24 2015. 5. 29. 2:21

उत्पाद की विशेषताएं

- **तीन गुना कूलिंग**

- फ़्रीज़र/फ़्रेश फ़ूड कंपार्टमेंट/कन्वर्टिबल कंपार्टमेंट प्रत्येक कन्डेंसर का उपयोग करके इष्टतम तापमान/नमी बनाए रख सकते हैं।
  और साथ ही गंध भी नहीं मिलेगी।

- **फ़्लेक्स क्षेत्र**

- यह फ़्रीज़र/कूलिंग/ठंडा चयन/पतली बर्फ़ विकल्पों का उपयोग करके विभिन्न प्रकार के संग्रहण में सक्षम है।

- **चिल**

- निर्धारित तापमान तकनीक ताज़ापन बनाए रखेगी।

DA68-03194K-00.indb 25 2015. 5. 29. 2:21

अपने Samsung रेफ़्रिजरेटर को संचालित करना

नियंत्रण पैनल का उपयोग करना

सामान्य मॉडल



(1) Fridge (फ़्रिज)

फ़्रिज को 1 °C और 7 °C के बीच के वाँछित तापमान पर सेट करने के लिए Fridge (फ़्रिज) बटन स्पर्श करें।
डिफ़ॉल्ट रूप से तापमान 3 °C पर सेट होता है और Fridge (फ़्रिज) बटन को बार-बार स्पर्श करने से तापमान अगले क्रम में बदलता जाता है और तापमान संकेतक वाँछित तापमान प्रदर्शित करता है।



(2) CoolSelect+ (ठंडा चयन कक्ष)

ठंडा चयन कक्ष रेफ़्रिजरेटर के निचले दाएँ कोने में स्थित होता है।
CoolSelect बटन ठंडा चयन कक्ष को 4 में से एक सेटिंग पर बदलता है; फ़्रीज़र, सॉफ़्ट फ़्रीज़िंग, चिल और कूल।
ठंडा चयन कक्ष सेटिंग को बदलने के लिए, बटन को कम से कम 3 सेकंड के लिए दबा कर रखें और फिर जब इच्छित मोड का चयन कर लिया जाए तो बटन को छोड़ दें।
बटन स्पर्श करने के 3 सेकंड के बाद मोड 1 सेकंड के अंतरालों पर परिवर्तित हो जाता है।

Freezer (फ़्रीज़र)

फ़्रीज़र के समान तापमान सेट करने के लिए फ़्रीज़र का चयन करें।

- इस सेटिंग का उपयोग जमे हुए भोजन को रखने के लिए करें।

Soft Freezing (सॉफ़्ट फ़्रीज़िंग)

तापमान को -5 °C पर सेट करने के लिए सॉफ़्ट फ़्रीज़िंग का चयन करें।

- इस सेटिंग का उपयोग मांस और मछलियों को फ़्रिज में अधिक समय तक रखने के लिए करें।

Chill (चिल)

तापमान को -1 °C पर सेट करने के लिए चिल का चयन करें।

- इस सेटिंग का उपयोग डेली स्टीक, मछली, बेकन और चीज़ को रखने के लिए करें।

Cool (ठंडा)

Cool (ठंडा) का उपयोग 2 °C तापमान सेट करने के लिए करें।

- इस सेटिंग का उपयोग पेय पदार्थ (जूस, सॉफ़्ट ड्रिंक और बियर) सब्ज़ियां, फल इत्यादि रखने के लिए करें।

DA68-03194K-00.indb 26 2015. 5. 29. 2:21

सावधानी

- [Freezer] फ़ंक्शन का उपयोग करने के बाद इसके फ़ंक्शन को परिवर्तित करने के लिए, मांस या जलयुक्त भोजन से मांस-रक्त या जल बाहर आ सकता है।

- यदि मांस या मछली को [Fridge] की सेटिंग पर संगहीत किया जाता है, तो यह खराब हो सकते हैं।
  यदि भोजन को Cool Select (ठंडा चयन) रूम की सेटिंग के अनुसार संग्रहीत किया जाता है, तो भोजन जम सकता है या खराब हो सकता है।

- जब बटन कार्य नहीं करती है, तो यह जांचे कि क्या यह लॉक पर सेट है।
  जब यह लॉक की गई हो, तो लॉक/अनलॉक करें बटन को 3 सेकंड या इससे अधिक समय तक तब तक दबाएं, जब तक कि अनलॉक आइकन ( ) प्रकाशमान न हो जाए।
  और फिर Cool Select (ठंडा चयन) रूम को 3 सेकंड या इससे अधिक समय के लिए स्पर्श करके सेटिंग परिवर्तित करें।
- जब सेटिंग पूर्ण हो, तो यह जांच करने के लिए डिस्प्ले की फिर से जांच करें कि क्या सेटिंग सही है।

(3) Freezer (फ़्रीज़र)

फ़्रीज़र को -15 °C और -23 °C के बीच के वाँछित तापमान पर सेट करने के लिए Freezer (फ़्रीज़र) बटन स्पर्श करें।
डिफ़ॉल्ट रूप से तापमान -19 °C पर सेट होता है और Freezer (फ़्रीज़र) बटन को बार-बार स्पर्श करने से तापमान अगले क्रम में बदलता जाता है और तापमान संकेतक वाँछित तापमान प्रदर्शित करता है।

-18 °C – -19 °C – -20 °C – -21 °C – -22 °C – -23 °C
-17 °C – -16 °C – -15 °C – पॉवर फ़्रीज़

- जब फ़्रिज या फ़्रीज़र घटकों का तापमान असामान्य रूप से बढ़ता है, तो फ़्रीज़र या फ़्रिज तापमान संकेतक ब्लिंक करेगा।
  (जब फ़्रिज या फ़्रीज़र घटकों का तापमान सामान्य हो जाता है, तो फ़्रीज़र या फ़्रिज तापमान संकेतक ब्लिंक करना बंद कर देगा। यदि तापमान संकेतक कुछ घंटों, के बाद ब्लिंक करना नहीं रुकता है, तो कृपया अपने सर्विस सेंटर से संपर्क करें।

Power Freezer (पॉवर फ़्रीज़र)

पावर फ़्रीज़ प्रकार्य, फ़्रीज़र कंप्रेसर की गति को महत्वपूर्ण रूप से बढ़ा देता है, जिसके कारण फ़्रीज़र आपके द्वारा चुने गए तापमान तक तेज़ी से ठंडा होता है।
यदि आपको किसी आइटम को तेज़ी से फ़्रीज़ करने की, अधिक मात्रा में बर्फ़ बनाने की या फ़्रीज़र के तेज़ी से गर्म होने पर (उदाहरण के लिए दरवाज़े को खुला छोड़ देने पर) उसे तेज़ी से ठंडा करने की आवश्यकता हो, तो पावर फ़्रीज़ उपयोगी होता है।
पावर फ़्रीज़ प्रकार्य को मैन्युअल रूप से बंद करने के लिए फ़्रीज़र बटन स्पर्श करें और फिर फ़्रीज़र का तापमान रिसेट करें।
पावर फ़्रीज़, ऊर्जा की खपत के लिए 50 घंटों के बाद स्वचालित रूप से बंद हो जाता है।
जब पावर फ़्रीज़ फ़ंक्शन स्वचालित रूप से रुक जाता है, तो यह फ़्रीज़र तापमान को -19 °C पर स्वचालित रूप से सेट कर देता है।
जब आप इस फ़ंक्शन का उपयोग करेंगे तो रेफ़्रिजरेटर की ऊर्जा खपत बढ़ जाएगी।
यदि आपको बड़ी मात्रा में भोजन फ़्रीज़ करने की जरूरत हो, तो कम से कम 20 घंटे पहले पावर फ़्रीज़ प्रकार्य सक्रिय करें।

(4) Lock Unlock (लॉक करना अनलॉक करना)

इस बटन को 3 सेकंड के लिए स्पर्श करने पर यह सभी बटन को लॉक कर देता है, अतः बटनों का उपयोग नहीं किया जा सकता है।
साथ ही, सभी बटनों को अनलॉक करने के लिए इस बटन का उपयोग 3 सेकंड के लिए पुनः करें।

DA68-03194K-00.indb 27 2015. 5. 29. 2:21

एग्ज़िबिशन मोड रद्द करना

सावधानी

- एग्ज़िबिशन मोड के मामले में, यह कार्य करता हुआ लगता है, लेकिन यह ठड़ी हवा उत्पन्न नहीं करता है।
  जब रेफ़्रिजरेटर सामान्य रूप से कार्य कर रहा हो, तो इस मोड को रद्द करने के लिए, लॉक और फ़्रीज़ कुंजियों को 6 सेकंड एक साथ दबा कर रखने से संपूर्ण डिस्प्ले पैनल लगभग 4 सेकंड के लिए हर 0.5 सेकंड में ब्लिंक करेगा।
  4 सेकंड के दौरान जबकि पूरा डिस्प्ले पैनल ब्लिंक करता है, यदि आप लॉक और फ़्रिज कुंजियों को छोड़ते हैं और "डिंग-डांग" ध्वनि आने तक आप फ़्रीज़र कुंजी को स्पर्श करते हैं।
  या आप पावर बंद करके एग्ज़िबिशन को रद्द कर सकते हैं।

तापमान को नियंत्रित करना

अनुशंसित फ़्रीज़र और फ़्रिज कंपार्टमेंट तापमान

फ़्रीज़र और फ़्रिज कंपार्टमेंट के अनुशंसित तापमान क्रमशः -19 °C और 3 °C हैं। यदि Freezer (फ़्रीजर) और Fridge (फ़्रिज) कम्पार्टमेंट का तापमान बहुत अधिक या कम हो, तामपान को मैन्युअल रूप से समायोजित करें।

फ़्रीज़र का तापमान नियंत्रित करना

अनुशंसित तापमान (फ़्रीज़र) : -19 °C

Freezer (फ़्रीज़र)

फ़्रीज़र को -15 °C और -23 °C के बीच के वाँछित तापमान पर सेट करने के लिए Freezer (फ़्रीज़र) बटन स्पर्श करें।
डिफ़ॉल्ट रूप से तापमान -19 °C पर सेट होता है और Freezer (फ़्रीज़र) बटन को बार-बार स्पर्श करने से तापमान अगले क्रम में बदलता जाता है और तापमान संकेतक वाँछित तापमान प्रदर्शित करता है।

DA68-03194K-00.indb 28 2015. 5. 29. 2:21



- जब फ़्रिज या फ़्रीज़र घटकों का तापमान असामान्य रूप से बढ़ता है, तो फ़्रीज़र या फ़्रिज तापमान संकेतक ब्लिंक करेगा।
  जब फ़्रीज़र या फ़्रिज का तापमान सामान्य हो जाता है, तो फ़्रीज़र या फ़्रिज का तापमान संकेतक ब्लिंक करना बंद कर देता है।
  यदि तापमान संकेतक कुछ घंटों, के बाद ब्लिंक करना नहीं रुकता है, तो कृपया अपने सर्विस सेंटर से संपर्क करें।

फ़्रिज का तापमान नियंत्रित करना

अनुशंसित तापमान (फ़्रिज) : 3 °C

फ़्रिज को 1 °C और 7 °C के बीच के वाँछित तापमान पर सेट करने के लिए Fridge (फ़्रिज) बटन स्पर्श करें।
डिफ़ॉल्ट रूप से तापमान 3 °C पर सेट होता है और Fridge (फ़्रिज) बटन को बार-बार स्पर्श करने से तापमान अगले क्रम में बदलता जाता है और तापमान संकेतक वाँछित तापमान प्रदर्शित करता है।



- जब आप दरवाज़ों को बहुत ज्यादा बार खोलते हैं या अगर बड़ी मात्रा में गर्म भोजन रेफ़्रिजरेटर में रखा जाता है तो फ़्रीज़र, फ़्रिज या कूल सिलेक्ट कक्ष का तापमान बढ़ सकता है।

- इसके कारण डिजिटल प्रदर्शन चमकने लगता है।
  फ़्रीज़र और फ़्रिज जब सामान्य तापमान पर वापस लौट जाते हैं तो चमकना बंद हो जाता है।
- अगर चमकना जारी रहता है, तो हो सकता ही आपको रेफ़्रिजरेटर को "रीसेट" करना पड़े।
  उपकरण का प्लग निकालें, लगभग 10 मिनट तक प्रतीक्षा करें और फिर बिजली के तार को वापस लगाएँ।
- यदि डिस्प्ले और मुख्य नियंत्रक के बीच कोई संचार त्रुटि होती है, तो डिस्प्ले ब्लिंक हो सकता है, “E-PC” लाइट ब्लिंक हो सकती है।
  यदि ब्लिंकिंग लंबे समय तक जारी रहती है, तो कृपया Samsung Electronics के सर्विस सेंटर पर संपर्क करें।

DA68-03194K-00.indb 29 2015. 5. 29. 2:21

पुर्ज़े और सुविधाएँ

रेफ़्रिजरेटर के पुर्ज़ों और सुविधाओं को और अच्छे से जानने के लिए इस पृष्ठ का उपयोग करें।



इस मॉडल के फ़्रीज़र के दरवाज़े के गाईस, शीर्ष गार्ड को छोड़कर दो स्टार सेक्शन होते हैं, अतः दो स्टार सेक्शन का तापमान अन्य फ़्रीज़र कंपार्टमेंट के तापमान से कुछ अधिक होता है।
दो स्टार सेक्शन (**1**) हैं।

दरवाज़ा बंद करते समय, अन्य दरवाज़े पर खरोंच लगने से बचने के लिए यह सुनिश्चित करें कि लम्बवत कब्जा अनुभाग सही पोज़िशन में हो। यदि लम्बवत कब्जा अनुभाग को विपरीत हो जाता है, तो उसे मौजूदा स्थिति में रखें और फिर दरवाज़ा बंद करें।
कभी कभी लम्बवत कब्जा सेक्शन में नमी दिखाई दे सकती है।
दरवाज़े का हैंडल समय के साथ ढीला हो सकता है।
यदि ऐसा होता है, तो दरवाज़े के भीतर मिलने वाले बोल्ट्स को कसें।
यदि आप किसी एक दरवाज़े को अत्यधिक बल से बंद कर देते हैं, तो दूसरा दरवाज़ा खुल सकता है।

यदि आंतरिक या बाहरी LED लैंप खराब हो जाता है, तो कृपया Samsung सेवा से संपर्क करें।

DA68-03194K-00.indb 30 2015. 5. 29. 2:21

बर्फ़ संग्रहण बॉक्स

यह बर्फ़ के क्यूब्स संग्रहीत करने के लिए होता है।
जब बर्फ़ की कोई खपत न हो, तो अधिक संग्रहण स्थान प्राप्त करने के लिए कंटेनर को रेफ्रिजरेटर के बाहर ले जाएं।

बर्फ़ स्टोरेज बॉक्स का उपयोग कैसे करें

1. सपोर्ट आइस ट्रे
- बर्फ़ की सपोर्ट ट्रे, यह किसी भी बाहरी पदार्थ को बर्फ़ में प्रविष्ट होने से रोकती है।

2. बर्फ़ की ट्रे
- इसका उपयोग बर्फ़ के क्यूब बनाने के लिए किया जाता है।

3. बर्फ़ का पात्र
- इसका उपयोग बनाए जा रहे बर्फ़ के क्यूब संग्रहीत करने के लिए किया जाता है।

- बर्फ़ ट्रे नॉब को घड़ी की दिशा ( ) में घुमा कर बनाए जा रहे बर्फ़ के क्यूब संग्रहीत करें।
- हो सकता है कि सभी बर्फ़ के क्यूब एक बार में ट्रे से अलग न हों।
  यदि ऐसा होता है तो बर्फ़ की ट्रे को एकाधिक बार मोड़ें।
- जमी हुई ग्रीन टी या दूध को बर्फ़ की ट्रे से अलग करना कठिन हो सकता है।
- बर्फ़ के पात्र को ऊपर उठाएं और उसे निकालने के लिए बाहर निकालें।





सावधानी
- बर्फ़ के क्यूब के संग्रहण के लिए किसी पारदर्शी बर्फ़ के पात्र में पानी न भरें। बर्फ़ का पात्र क्रैक हो सकता है।

- पारदर्शी बर्फ़ के पात्र के निचले भाग में एक जल ड्रेन छिद्र होता है, जिसे पानी अंदर रुकने से बचाने के लिए डिज़ाइन किया जाता है।
- शून्य से अधिक तापमान पर बर्फ़ के क्यूब संग्रहीत करते समय, आइस पिघल कर बर्फ़ के पात्र से बाहर बह सकती है।
- बर्फ़ कुछ समय तक पावर बंद रहने के कारण पिघल कर बर्फ़ के पात्र से बाहर निकल सकती है।
  इसके साथ ही, जब पिघला कर बना हुआ पानी फिर से जम जाता है, तो इससे बर्फ़ का पात्र टूट सकता है।
  (पिघल कर बने हुए पानी को निकालने के बाद बर्फ़ के पात्र का उपयोग करें।)

रेफ्रिजरेटर के सहायक उपकरणों को निकलना

1. दरवाज़े का पात्र या गार्ड कंपार्टमेंट
- निकालने के लिए - बस पात्र को थोड़ा ऊपर उठाएं और सीधा बाहर खींच लें।
- पुनर्स्थापित करने के लिए - उसे वांछित पोज़िशन के ऊपर तक स्लाइड इन करें और नीचे धकेलें जब तक कि यह रुक नहीं जाता है।

सावधानी
- यदि दरवाज़े का पात्र दरवाज़ों से दृढ़ता से जुड़ी हुई नहीं हैं, तो चोट लग सकती हैं।
  बच्चों को इससे लंबे समय तक खेलने की अनुमति न दें।
  पात्र के नुकीले किनारों से चोट लग सकती है।

- भोजन से भरे पात्र को समायोजित न करें।
  सबसे पहले भोजन को निकालें।



- धूल को निकालने की विधि - गार्ड को निकालें और उसे पानी से धोएं।

- यदि यह उपयोग के बाद बर्फ़ से मैला हो गया हो, तो उसे पानी में धोएं।



DA68-03194K-00.indb 31 2015. 5. 29. 2:21

2. टेम्पर किए गए ग्लास शेल्फ़

- निकालने के लिए - शेल्फ़ के सामने का भाग दिखाई गई दिशा (1) में मोड़ें और उसे लम्बवत (2) ऊपर उठाएं। शेल्फ़ को बाहर खींचें।
- पुनर्स्थापित करने के लिए - शेल्फ़ के सामने का भाग ऊपर झुकाएं और शेल्फ़ के हुक को स्लॉट में वांछित ऊंचाई पर निर्देशित करें।
  इसके बाद, शेल्फ़ के सामने वाले भाग को नीचे करें ताकि हुक स्लॉट में गिर जाएं।

सावधानी

- टेंपर किए गए ग्लास शेल्फ़ भारी होते हैं। उन्हें निकालते समय विशेष सावधानी का उपयोग करें।



3. सब्ज़ी और फ़ल के ड्रॉवर (EZ फ़्रेश क्षेत्र)

- ड्रॉवर को एक हाथ से पकड़ कर, उसे आगे की ओर खींचते हुए थोड़ा ऊपर उठाएं और फिर उसे रेफ़्रिजरेटर से बाहर खींचें।

- दरवाज़ा के पात्र को होने वाले नुक्सान से बचाने के लिए ड्रॉवर निकालने के पहले दरवाज़े का पात्र निकालें।



रेफ़्रिजरेटर को साफ करना

चेतावनी

- रेफ़्रिजरेटर की सफाई के लिए बेंजीन, थिनर या क्लोरोक्स या कार डिटर्जेंट का उपयोग न करें। वे उपकरण की सतह को क्षति पहुँचा सकते हैं और आग लगा सकते हैं।

- बिजली का प्लग लगा होने पर रेफ़्रिजरेटर पर पानी का स्प्रे न करें, इससे बिजली का झटका लग सकता है।

- रेफ़्रिजरेटर को साफ करने के लिए, निम्न चरणों का पालन करें:

1. रेफ़्रिजरेटर की बिजली की तार को प्लग से निकाल दें।
2. मुलायम रोएँ रहित कपड़े या काग़ज के तौलियो को थोड़ा पानी में भिगाएँ।

रेफ़्रिजरेटर को साफ़ करने के लिए किसी भी प्रकार के डिटर्जेंट का उपयोग न करें क्योंकि इससे रेफ़्रिजरेटर का रंग उड़ सकता है या उसे क्षति पहुंच सकती है।

3. रेफ़्रिजरेटर के साफ और सूखा होने तक उसे भीतर और बाहर से पोछें।
4. रेफ़्रिजरेटर के पावर कोड को प्लग में लगाएँ।

आंतरिक लाइट बदलना

फ़्रीज़र / फ़्रिज LED लैंप

- अगर LED लैंप कवर बाहरी पदार्थों से गंदा हो गया है, तो हो सकता है कि LED लैंप स्पष्ट प्रकाश न दे। पूरी चमकती रौशनी वापस पाने के लिए सतही कवर को साफ सूखे कपड़े से साफ करें।

सावधानी

- LED टाइप को स्वयं न निकालें या प्रतिस्थापित न करें।
  LED लाइट प्रतिस्थापित करने के लिए, Samsung सेवा केंद्र या अपने प्राधिकृत Samsung डीलर से संपर्क करें।

अगर आप स्वयं LED लैंप को प्रतिस्थापित करने का प्रयास करते हैं, तो आप बिजली के झटके या गंभीर निजी चोट का जोखिम उठाते हैं।

DA68-03194K-00.indb 32 2015. 5. 29. 2:21

समस्या-निवारण

समस्या	समाधान
रेफ़्रिजरेटर बिल्कुल कार्य नहीं कर रहा है या यह पर्याप्त रूप से ठंडा नहीं कर रहा है।	• जाँचें कि पावर प्लग समुचित रूप से कनेक्ट है। • जाँचें कि डिजिटल डिस्प्ले पर सेट किया गया तापमान फ़्रीज़र या फ़्रिज के आंतरिक तापमान से अधिक है। यदि ऐसा है, तो फ़्रीज़र या फ़्रिज को ठंडे तापमान में रखें। • क्या रेफ़्रिजरेटर सीधी धूप में या किसी गर्म स्रोत के पास स्थित है? यदि हाँ, तो वह पर्याप्त रूप से ठंडा करने में सक्षम नहीं होगा। इसे ऐसी जगह पर स्थापित करें जहाँ सीधे धूप न पड़ती हो और ताप स्रोत समीप न हो। • क्या रेफ़्रिजरेटर का पिछला भाग दीवार के बहुत पास है और उचित वायु-निकास को अवरूद्ध कर रहा है? यदि हाँ, तो वह पर्याप्त रूप से ठंडा करने में सक्षम नहीं होगा। उसे दीवार से उचित दूरी पर रखें। • क्या अंदर बहुत अधिक खाद्य-सामग्री है जिससे खाद्य-पदार्थ निकास वायु-मार्ग को बाधित कर रहा है? रेफ़्रिजरेटर को उपयुक्त तापमान पर रखने के लिए, रेफ़्रिजरेटर में बहुत अधिक खाद्य-सामग्री न भरें।
फ़्रिज में रखा भोजन जमा हुआ है।	• जाँच करें कि डिजिटल डिस्प्ले पर सेट किया गया तापमान बहुत कम है। यदि ऐसा है, तो रेफ़्रिजरेटर के भीतर का तापमान बढ़ा कर उसे सेट करें। • क्या कमरे का तापमान बहुत कम है? रेफ़्रिजरेटर को गर्म पर सेट करें। • क्या आपने फ़्रिज के सबसे ठंडे भाग में या कूलिंग आउटलेट वेंट में पानी की अधिक मात्रा वाला भोजन संग्रहीत किया है? उन आइटम को फ़्रिज के अधिक ठंडे क्षेत्रों या पात्रों में रखने के बजाय फ़्रिज की अलग शेल्फ़ में रखने का प्रयास करें।
आपको असामान्य शोर या ध्वनियाँ सुनाई देती हैं।	• जाँचें कि क्या रेफ़्रिरजरेटर संतुलित और स्थिर है। • क्या रेफ़्रिजरेटर का पिछला भाग दीवार के बहुत पास है और उचित वायु-निकास को अवरूद्ध कर रहा है? • क्या रेफ़्रिजरेटर के पीछे या नीचे कोई चीज़ गिर गई है? • अगर आपके उपकरण के भीतर "टिक-टिक" की आवाज़ सुनाई दे सकती है; यह सामान्य है। जब तापमान परिवर्तन के कारण विविध साहयक उपकरण संकुचित या विस्तृत होते हैं तब टिक-टिक की आवाज़ सुनाई देती है। • यदि ऐसी आवाज़ आती है, जैसे कोई चीज़ किसी चीज़ से टकरा रही है, या कुछ अन्य चीज़ रेफ़्रिजरेटर के भीतर है, तो यह सामान्य है। यह ध्वनि, उच्च क्षमता पर संचालित होने वाले कंप्रेशर द्वारा उत्पन्न होती है।
उपकरण केबिनेट दरवाजा सीलिंग क्षेत्र गर्म हैं और संघनन हो रहा है।	• थोड़ी गर्मी सामान्य है क्योंकि संघनन से बचने के लिए रेफ़्रिजरेटर के लम्बवअत कब्जा अनुभाग में संघनन रोधी लगे हैं। • क्या रेफ़्रिजरेटर का दरवाज़ा थोड़ा सा खुला है? अगर आप दरवाज़े को लंबे समय तक खुला छोड़ देते हैं तो संघनन हो सकता है।
आप रेफ़्रिजरेटर में पानी के बुदबुदाने की आवाज़ सुन सकते हैं।	• यह सामान्य है। बुदबुदाने की आवाज़ रेफ़्रिजरेटर से होकर रेफ़्रिजरेंट के वितरण के कारण आती है।

DA68-03194K-00.indb 33 2015. 5. 29. 2:21

समस्या	समाधान
रेफ़्रिजरेटर के भीतर बदबू हो रही है।	• खराब हो चुके भोजन के लिए जाँच करें। • तेज़ गंध वाले भोजन (उदाहरण के लिए मछली) को कस कर कवर किया गया होना चाहिए। • समय-समय पर अपने फ़्रीज़र की सफ़ाई करें और किसी भी खराब या संदेहास्पद भोजन के फेंक दें।
फ़्रीज़र की दीवारों पर तुषार जम गया है।	• क्या वायु छिद्र अवरोधित हैं? किसी भी अवरोध को निकाल दें ताकि वायु स्वतंत्रता से प्रवाहित हो सके। • प्रभावी वायु प्रवाह के लिए संग्रहीत भोजन के बीच पर्याप्त स्थान रखें। • क्या फ़्रीज़र का दराज़ ठीक से बंद है?
ऑटो क्लोज़ सिस्टम फ़्रीज़र के दरवाज़े के साथ कार्य नहीं करता।	• क्या दरवाज़े के दाएं और बाएं भागों में कोई असंतुलन मौजूद है? • दरवाज़े को धीरे से 1~2 बार खोलें और बंद करें। आपके द्वारा यह कर लेने पर, ऑटो क्लोज़ सिस्टम सामान्य रूप से फिर से उचित कार्य करने लगता है। • दरवाज़े के दाएं भाग और बाएं भाग के असंतुलन से बचने के लिए दरवाज़े को धीरे से खोलने का प्रयास करें।

DA68-03194K-00.indb 34 2015. 5. 29. 2:21

मेमो

परिवेशी कक्ष तापमान सीमाएँ

इस रेफ़्रिजेरटर को उस परिवेशी तापमान में संचालित करने के लिए डिज़ाइन किया गया है जो रेटिंग प्लेट पर चिह्नित इसकी तापमान श्रेणी द्वारा निर्दिष्ट है।

श्रेणी	प्रतीक	परिवेशी तापमान सीमा (°C)	
		IEC 62552 (ISO 15502)	ISO 8561
विस्तृत परिमित	SN	+10 से +32 तक	+10 से +32 तक
परिमित	N	+16 से +32 तक	+16 से +32 तक
उपोष्णकटिबंधीय	ST	+16 से +38 तक	+18 से +38 तक
उष्णकटिबंधीय	T	+16 से +43 तक	+18 से +43 तक

फ़्रिज/फ़्रीज़र के स्थान, परिवेश के तापमान और आपके द्वारा दरवाज़ा खोले जाने की आवृत्ति जैसे कारकों से रेफ़्रिजरेटर का आंतरिक तापमान प्रभावित हो सकता है। इन कारकों की प्रतिपूर्ति करने के लिए तापमान को आवश्यकतानुसार समायोजित करें।

हिंदी

इस उत्पाद का सही निपटान

(अपशिष्ट इलेक्ट्रिकल और इलेक्ट्रॉनिक उपकरण)

(पृथक संग्रहण प्रणालियों वाले देशों में लागू)

इस उत्पाद, सहायक उपकरणों या इसके दस्तावेज़ों पर स्थित चिह्नांकन दर्शाता है कि इस उत्पाद, इसके इलेक्ट्रॉनिक सहायक उपकरणों (जैसे चार्जर, हैडसेट, USB केबल) का जीवनकाल समाप्त होने पर उनका निपटान अन्य घरेलू कचरे के साथ नहीं किया जाना चाहिए। अनियंत्रित अपशिष्ट निपटान से पर्यावरण और मनुष्यों को होने वाले नुकसान को रोकने के लिए, कृपया इन आइटम को अन्य प्रकार के कचरे से अलग कर दें और सामग्री संसाधनों के दीर्घकालिक पुनः उपयोग को बढ़ावा देने के लिए उन्हें ज़िम्मेदारी से रिसाइकल करें।

पर्यावरणीय रूप से सुरक्षित रिसाइकलिंग के लिए उत्पाद कहाँ और कैसे ले जाना है, इसके विवरण के लिए घरेलू उपयोगकर्ताओं को या तो उस विक्रेता से संपर्क करना चाहिए जिससे उन्होंने उत्पाद खरीदा था या अपने स्थानीय सरकारी कार्यालय से संपर्क करना चाहिए।

व्यावसायिक उपयोगकर्ताओं को अपने आपूर्तिकर्ता से संपर्क करना चाहिए और खरीद अनुबंध की नियम और शर्तें जाँचनी चाहिए। यह उत्पाद और इसके इलेक्ट्रॉनिक सहायक उपकरणों को निपाटन के लिए अन्य वाणिज्यिक कचरे का साथ नहीं मिलाना चाहिए।

SAMSUNG WORLD WIDE से संपर्क करें
यदि Samsung उत्पादों के बारे में आपके कोई प्रश्न या टिप्पणियां हैं,
कृपया SAMSUNG ग्राहक सहायता केंद्र से संपर्क करें।

Samsung India Electronics Pvt. Ltd. 2रा, 3रा और 4था तल, टॉवर--C, विपुल टेक स्क्वॉयर,
सेक्टर 43, गोल्फ़ कोर्स रोड, गुड़गाँव, हरियाणा, भारत-122002
1800 3000 8282 - टोल फ़्री
1800 266 8282 - टोल फ़्री
www.samsung.com/in/support

This product is RoHS compliant

DA68-03194K-00